



Monitoring NetApp Filers

eG Innovations Product Documentation

Table of Contents

| | |
|---|----|
| CHAPTER 1: INTRODUCTION | 1 |
| CHAPTER 2: HOW TO MONITOR NETAPP FILER USING EG ENTERPRISE? | 2 |
| 2.1 Managing the NetApp Filer | 2 |
| 2.2 Configuring the tests | 3 |
| CHAPTER 3: MONITORING NETAPP FILER | 4 |
| 3.1 The NA Hardware Layer | 4 |
| 3.1.1 NetApp Hardware Test | 5 |
| 3.2 The NA System Layer | 8 |
| 3.2.1 NetApp System Test | 8 |
| 3.3 The Network Layer | 11 |
| 3.4 The NA Disk Layer | 11 |
| 3.4.1 NetApp Disks Test | 12 |
| 3.5 The NA File System Layer | 15 |
| 3.5.1 NetApp File Systems Test | 15 |
| 3.5.2 NetApp File Status Test | 18 |
| 3.6 The NA File Service Layer | 20 |
| 3.6.1 NetApp RPC Test | 20 |
| 3.6.2 NetApp NFS Test | 23 |
| 3.6.3 NetApp CIFS Test | 26 |
| ABOUT EG INNOVATIONS | 29 |

Table of Figures

| | |
|---|----|
| Figure 2.1: Adding a new NetApp Filer | 3 |
| Figure 2.2: List of unconfigured tests for the NetApp Filer | 3 |
| Figure 3.1: The layer model of a NetApp Filer | 4 |
| Figure 3.2: The tests associated with the NA Hardware layer | 4 |
| Figure 3.3: The tests associated with the NA System layer | 8 |
| Figure 3.4: The tests associated with the Network layer | 11 |
| Figure 3.5: The tests associated with the NA Disk layer | 12 |
| Figure 3.6: The tests associated with the NA File System layer | 15 |
| Figure 3.7: the tests associated with the NA File Service layer | 20 |

Chapter 1: Introduction

The NetApp filer is a storage networking system built on the Data ONTAP operating system. It provides simultaneous file system access to UNIX, NT, and Web-based servers and clients using various file system access protocols like NFS, CIFS etc. Capable of handling terabytes of data, the NetApp Filer serves as a reliable and scalable storage solution for large enterprises and service providers.

For the NetApp Filer to provide storage services without any interruptions, the hardware on the filer should remain fault-free, adequate storage resources should be available on the filer, the load on the filer should be kept optimal, and most importantly, the file system access protocols should operate normally. In order to ensure this, all the above-mentioned performance-impacting factors should be kept under a constant check – in other words, should be continuously monitored. For this purpose, eG Enterprise offers a specialized monitoring model for continuously tracking the performance of the NetApp Filer.

Chapter 2: How to Monitor NetApp Filer Using eG Enterprise?

eG Enterprise monitors the NetApp Filer using a single eG external agent on any remote host in the environment. This agent is capable of polling the SNMP MIB of the NetApp Filer at regular intervals and fetching statistics related to its performance. To enable the eG agent to monitor the SNMP MIB of the NetApp Filer, SNMP access to the NetApp filer for eG agents.

The broad steps for monitoring NetApp Filer using eG Enterprise are as follows:

- Managing the NetApp Filer
- Configuring the tests

These steps have been discussed in following sections.

2.1 Managing the NetApp Filer

The eG Enterprise cannot automatically discover the NetApp Filer. This implies that you need to manually add the component for monitoring. Remember that the eG Enterprise automatically manages the components that are added manually. To manage a NetApp Filer component, do the following:

1. Log into the eG administrative interface.
2. Follow the Components -> Add/Modify menu sequence in the **Infrastructure** tile of the **Admin** menu.
3. In the **COMPONENT** page that appears next, select *NetApp Filer* as the **Component type**. Then, click the **Add New Component** button. This will invoke Figure 2.1.

COMPONENT

This page enables the administrator to provide the details of a new component

| | |
|----------|----------------|
| Category | Component type |
| All | NetApp Filer |

Component information

| | |
|--------------|--------------|
| Host IP/Name | 192.168.10.1 |
| Nick name | npfiler |

Monitoring approach

| | |
|-----------------|--------------|
| External agents | 192.168.9.70 |
|-----------------|--------------|

Add

Figure 2.1: Adding a new NetApp Filer

4. Specify the **Host IP** and the **Nick name** for the NetApp Filer in Figure 2.1. Then, click the **Add** button to register the changes.

2.2 Configuring the tests

1. When you attempt to sign out of eG administrative interface, a list of unconfigured tests will appear as shown in Figure 2.2. This list reveals the unconfigured tests requiring manual configuration.

| List of unconfigured tests for 'NetApp Filer' | | |
|---|---------------------|-----------------|
| Performance | | |
| Device Uptime | NetApp CIFS | NetApp Disks |
| NetApp File Status | NetApp File Systems | NetApp Hardware |
| NetApp NFS | NetApp RPC | NetApp System |

Figure 2.2: List of unconfigured tests for the NetApp Filer

2. To configure the tests, click on the test names in the list of unconfigured tests. For the details on configuring the tests, refer to [Monitoring NetApp Filer](#) chapter.
3. Once all the tests are configured, signout of the eG administrative interface.

Chapter 3: Monitoring NetApp Filer

eG Enterprise provides an exclusive NetApp Filer monitoring model (see Figure 3.1), which scans the entire filer from its file system to its hardware for errors, and reports abnormalities (if any).




Figure 3.1: The layer model of a NetApp Filer

Each layer depicted by Figure 3.1 is mapped to a set of tests, which when executed, contact the SNMP MIB of the filer to extract the statistics of interest.

The sections to come discuss each of the layers and the metrics they help collect.

3.1 The NA Hardware Layer

Using the NaHardware test, this layer brings to light faulty filer hardware.



Figure 3.2: The tests associated with the NA Hardware layer

3.1.1 NetApp Hardware Test

This test reports performance statistics pertaining to the NetApp filer hardware.

Target of the test : A NetApp filer

Agent deploying the test : An external agent

Outputs of the test : One set of results for a NetApp filer being monitored.

Configurable parameters for the test

| Parameter | Description |
|---------------|---|
| Test period | How often should the test be executed. |
| Host | The IP address of the host for which this test is to be configured. |
| SNMPPort | The port at which the monitored target exposes its SNMP MIB; the default is 161. |
| SNMPVersion | By default, the eG agent supports SNMP version 1. Accordingly, the default selection in the SNMPVersion list is v1 . However, if a different SNMP framework is in use in your environment, say SNMP v2 or v3 , then select the corresponding option from this list. |
| SNMPCommunity | The SNMP community name that the test uses to communicate with the storage. This parameter is specific to SNMP v1 and v2 only. Therefore, if the SNMPVersion chosen is v3 , then this parameter will not appear. |
| Username | This parameter appears only when v3 is selected as the SNMPVersion. SNMP version 3 (SNMPv3) is an extensible SNMP Framework which supplements the SNMPv2 Framework, by additionally supporting message security, access control, and remote SNMP configuration capabilities. To extract performance statistics from the MIB using the highly secure SNMP v3 protocol, the eG agent has to be configured with the required access privileges – in other words, the eG agent should connect to the MIB using the credentials of a user with access permissions to be MIB. Therefore, specify the name of such a user against this parameter. |
| Context | This parameter appears only when v3 is selected as the SNMPVersion. An SNMP context is a collection of management information accessible by an SNMP entity. An item of management information may exist in more than one context and an SNMP entity potentially has access to many contexts. A context is identified by the SNMPEngineID value of the entity hosting the management information (also called a contextEngineID) and a context name that identifies the specific context (also called a contextName). If the Username provided is associated with a context name, then the |

| Parameter | Description |
|------------------|---|
| | eG agent will be able to poll the MIB and collect metrics only if it is configured with the context name as well. In such cases therefore, specify the context name of the Username in the Context text box. By default, this parameter is set to none . |
| AuthPass | Specify the password that corresponds to the above-mentioned Username. This parameter once again appears only if the SNMPVersion selected is v3 . |
| Confirm Password | Confirm the AuthPass by retyping it here. |
| AuthType | This parameter too appears only if v3 is selected as the SNMPVersion. From the AuthType list box, choose the authentication algorithm using which SNMP v3 converts the specified username and password into a 32-bit format to ensure security of SNMP transactions. You can choose between the following options: <ul style="list-style-type: none"> • MD5 – Message Digest Algorithm • SHA – Secure Hash Algorithm |
| EncryptFlag | This flag appears only when v3 is selected as the SNMPVersion. By default, the eG agent does not encrypt SNMP requests. Accordingly, the this flag is set to No by default. To ensure that SNMP requests sent by the eG agent are encrypted, select the Yes option. |
| EncryptType | If this EncryptFlag is set to Yes , then you will have to mention the encryption type by selecting an option from the EncryptType list. SNMP v3 supports the following encryption types: <ul style="list-style-type: none"> • DES – Data Encryption Standard • AES – Advanced Encryption Standard |
| EncryptPassword | Specify the encryption password here. |
| Confirm Password | Confirm the encryption password by retyping it here. |
| Timeout | Specify the duration (in seconds) within which the SNMP query executed by this test should time out in this text box. The default is 10 seconds. |
| Data Over TCP | By default, in an IT environment, all data transmission occurs over UDP. Some environments however, may be specifically configured to offload a fraction of the data traffic – for instance, certain types of data traffic or traffic pertaining to specific components – to other protocols like TCP, so as to prevent UDP overloads. In such environments, you can instruct the eG agent to conduct the SNMP data traffic related to the monitored target over TCP (and not UDP). For this, set this flag to Yes . By default, this flag is set to No . |

| Parameter | Description |
|--------------------|--|
| Detailed Diagnosis | <p>To make diagnosis more efficient and accurate, the eG Enterprise suite embeds an optional detailed diagnostic capability. With this capability, the eG agents can be configured to run detailed, more elaborate tests as and when specific problems are detected. To enable the detailed diagnosis capability of this test for a particular server, choose the On option. To disable the capability, click on the Off option.</p> <p>The option to selectively enable/disable the detailed diagnosis capability will be available only if the following conditions are fulfilled:</p> <ul style="list-style-type: none"> • The eG manager license should allow the detailed diagnosis capability • Both the normal and abnormal frequencies configured for the detailed diagnosis measures should not be 0. |

Measurements made by the test

| Measurement | Description | Measurement Unit | Interpretation |
|--------------------------|--|------------------|--|
| Over temperature | Indicates whether the hardware is currently operating above its maximum rated temperature. | Number | A value of 1 indicates over temperature and 0 indicates normal temperature. |
| Failed fan count | Indicates the number of main unit backplane fans, the working status of which has currently changed. | Number | The detailed diagnosis capability, if enabled for this test, will list the fans that have failed and the reason for their failure. |
| Failed powersupply count | Indicates the number of power supplies and power rails, the working status of which has currently changed. | Number | The detailed diagnosis capability, if enabled for this test, will list the power rails that have failed and the reason for their failure. |
| Nvram battery status | Indicates the current status of the NVRAM battery or batteries. | Number | A value of 0 indicates a problem, and 1 indicates that the battery is functioning normally. The detailed diagnosis capability, if enabled for this test, will provide a brief description of the problem (if any). |

| Measurement | Description | Measurement Unit | Interpretation |
|-------------|-------------|------------------|--|
| | | | Batteries which are fully or partially discharged may not fully protect the system during a crash. |

3.2 The NA System Layer

This layer reveals how well the system resources are utilized by the NetApp filer.



Figure 3.3: The tests associated with the NA System layer

3.2.1 NetApp System Test

This test monitors the usage of system resources by the NetApp filer.

Target of the test : A NetApp filer

Agent deploying the test : An external agent

Outputs of the test : One set of results for a NetApp filer being monitored.

Configurable parameters for the test

| Parameter | Description |
|-------------|---|
| Test period | How often should the test be executed. |
| Host | The IP address of the host for which this test is to be configured. |
| SNMPPort | The port at which the monitored target exposes its SNMP MIB; the default is 161. |
| SNMPVersion | By default, the eG agent supports SNMP version 1. Accordingly, the default selection in the SNMPVersion list is v1. However, if a different SNMP framework is in use in |

| Parameter | Description |
|------------------|--|
| | your environment, say SNMP v2 or v3 , then select the corresponding option from this list. |
| SNMPCommunity | The SNMP community name that the test uses to communicate with the storage. This parameter is specific to SNMP v1 and v2 only. Therefore, if the SNMPVersion chosen is v3 , then this parameter will not appear. |
| Username | This parameter appears only when v3 is selected as the SNMPVersion. SNMP version 3 (SNMPv3) is an extensible SNMP Framework which supplements the SNMPv2 Framework, by additionally supporting message security, access control, and remote SNMP configuration capabilities. To extract performance statistics from the MIB using the highly secure SNMP v3 protocol, the eG agent has to be configured with the required access privileges – in other words, the eG agent should connect to the MIB using the credentials of a user with access permissions to be MIB. Therefore, specify the name of such a user against this parameter. |
| Context | This parameter appears only when v3 is selected as the SNMPVersion. An SNMP context is a collection of management information accessible by an SNMP entity. An item of management information may exist in more than one context and an SNMP entity potentially has access to many contexts. A context is identified by the SNMPEngineID value of the entity hosting the management information (also called a contextEngineID) and a context name that identifies the specific context (also called a contextName). If the Username provided is associated with a context name, then the eG agent will be able to poll the MIB and collect metrics only if it is configured with the context name as well. In such cases therefore, specify the context name of the Username in the Context text box. By default, this parameter is set to <i>none</i> . |
| AuthPass | Specify the password that corresponds to the above-mentioned Username. This parameter once again appears only if the SNMPVersion selected is v3 . |
| Confirm Password | Confirm the AuthPass by retyping it here. |
| AuthType | This parameter too appears only if v3 is selected as the SNMPVersion. From the AuthType list box, choose the authentication algorithm using which SNMP v3 converts the specified username and password into a 32-bit format to ensure security of SNMP transactions. You can choose between the following options: <ul style="list-style-type: none"> • MD5 – Message Digest Algorithm • SHA – Secure Hash Algorithm |
| EncryptFlag | This flag appears only when v3 is selected as the SNMPVersion. By default, the eG agent does not encrypt SNMP requests. Accordingly, the this flag is set to No by default. To ensure that SNMP requests sent by the eG agent are encrypted, select the |

| Parameter | Description |
|------------------|---|
| | Yes option. |
| EncryptType | If this EncryptFlag is set to Yes , then you will have to mention the encryption type by selecting an option from the EncryptType list. SNMP v3 supports the following encryption types: <ul style="list-style-type: none"> • DES – Data Encryption Standard • AES – Advanced Encryption Standard |
| EncryptPassword | Specify the encryption password here. |
| Confirm Password | Confirm the encryption password by retyping it here. |
| Timeout | Specify the duration (in seconds) within which the SNMP query executed by this test should time out in this text box. The default is 10 seconds. |
| Data Over TCP | By default, in an IT environment, all data transmission occurs over UDP. Some environments however, may be specifically configured to offload a fraction of the data traffic – for instance, certain types of data traffic or traffic pertaining to specific components – to other protocols like TCP, so as to prevent UDP overloads. In such environments, you can instruct the eG agent to conduct the SNMP data traffic related to the monitored target over TCP (and not UDP). For this, set this flag to Yes . By default, this flag is set to No . |

Measurements made by the test

| Measurement | Description | Measurement Unit | Interpretation |
|--------------------------------|--|------------------|--|
| Cpu busy time | Indicates the percentage of time that the CPU was busy during the last measurement period. | Percent | A high value may be indicative of excessive load on the appliance. |
| Global status | Indicates the overall status of the appliance. | | |
| Data received over the network | Indicates the rate of data received by all the network interfaces. | Bytes/Sec | |
| Data sent over the network | Indicates the rate of data transmitted by all the network interfaces. | Bytes/Sec | |

| Measurement | Description | Measurement Unit | Interpretation |
|-------------|---|------------------|--|
| Disk reads | Indicates the rate of data read from the disk. | Reads/Sec | A dramatic increase in this value may be indicative of an I/O bottleneck on the appliance. |
| Disk writes | Indicates the rate of data written to the disk. | Writes/Sec | A dramatic increase in this value may be indicative of an I/O bottleneck on the appliance. |

3.3 The Network Layer

Using the **Network** test, the **Network** layer indicates whether or not the NetApp filer is available over the network.




Figure 3.4: The tests associated with the Network layer

This test has been dealt with extensively in the *Monitoring Unix and Windows Servers* document.

3.4 The NA Disk Layer

The test associated with this layer monitors the disk usage on the filer.



Figure 3.5: The tests associated with the NA Disk layer

3.4.1 NetApp Disks Test

This test monitors the disk drives of the NetApp filer.

Target of the test : A NetApp filer

Agent deploying the test : An external agent

Outputs of the test : One set of results for a NetApp filer being monitored.

Configurable parameters for the test

| Parameter | Description |
|---------------|--|
| Test period | How often should the test be executed. |
| Host | The IP address of the host for which this test is to be configured. |
| SNMPPort | The port at which the monitored target exposes its SNMP MIB; the default is 161. |
| SNMPVersion | By default, the eG agent supports SNMP version 1. Accordingly, the default selection in the SNMPVersion list is v1 . However, if a different SNMP framework is in use in your environment, say SNMP v2 or v3 , then select the corresponding option from this list. |
| SNMPCommunity | The SNMP community name that the test uses to communicate with the storage. This parameter is specific to SNMP v1 and v2 only. Therefore, if the SNMPVersion chosen is v3 , then this parameter will not appear. |
| Username | This parameter appears only when v3 is selected as the SNMPVersion. SNMP version 3 (SNMPv3) is an extensible SNMP Framework which supplements the SNMPv2 Framework, by additionally supporting message security, access control, and remote SNMP configuration capabilities. To extract performance statistics from the MIB using |

| Parameter | Description |
|------------------|--|
| | the highly secure SNMP v3 protocol, the eG agent has to be configured with the required access privileges – in other words, the eG agent should connect to the MIB using the credentials of a user with access permissions to be MIB. Therefore, specify the name of such a user against this parameter. |
| Context | This parameter appears only when v3 is selected as the SNMPVersion. An SNMP context is a collection of management information accessible by an SNMP entity. An item of management information may exist in more than one context and an SNMP entity potentially has access to many contexts. A context is identified by the SNMPEngineID value of the entity hosting the management information (also called a contextEngineID) and a context name that identifies the specific context (also called a contextName). If the Username provided is associated with a context name, then the eG agent will be able to poll the MIB and collect metrics only if it is configured with the context name as well. In such cases therefore, specify the context name of the Username in the Context text box. By default, this parameter is set to <i>none</i> . |
| AuthPass | Specify the password that corresponds to the above-mentioned Username. This parameter once again appears only if the SNMPVersion selected is v3 . |
| Confirm Password | Confirm the AuthPass by retying it here. |
| AuthType | This parameter too appears only if v3 is selected as the SNMPVersion. From the AuthType list box, choose the authentication algorithm using which SNMP v3 converts the specified username and password into a 32-bit format to ensure security of SNMP transactions. You can choose between the following options: <ul style="list-style-type: none"> • MD5 – Message Digest Algorithm • SHA – Secure Hash Algorithm |
| EncryptFlag | This flag appears only when v3 is selected as the SNMPVersion. By default, the eG agent does not encrypt SNMP requests. Accordingly, the this flag is set to No by default. To ensure that SNMP requests sent by the eG agent are encrypted, select the Yes option. |
| EncryptType | If this EncryptFlag is set to Yes , then you will have to mention the encryption type by selecting an option from the EncryptType list. SNMP v3 supports the following encryption types: <ul style="list-style-type: none"> • DES – Data Encryption Standard • AES – Advanced Encryption Standard |
| EncryptPassword | Specify the encryption password here. |

| Parameter | Description |
|------------------|---|
| Confirm Password | Confirm the encryption password by retyping it here. |
| Timeout | Specify the duration (in seconds) within which the SNMP query executed by this test should time out in this text box. The default is 10 seconds. |
| Data Over TCP | By default, in an IT environment, all data transmission occurs over UDP. Some environments however, may be specifically configured to offload a fraction of the data traffic – for instance, certain types of data traffic or traffic pertaining to specific components – to other protocols like TCP, so as to prevent UDP overloads. In such environments, you can instruct the eG agent to conduct the SNMP data traffic related to the monitored target over TCP (and not UDP). For this, set this flag to Yes . By default, this flag is set to No . |

Measurements made by the test

| Measurement | Description | Measurement Unit | Interpretation |
|--------------------------|---|------------------|----------------|
| Total disk count | Indicates the total number of disks on the system. | Number | |
| Active disk count | Indicates the number of disks which are currently active, including parity disks. | Number | |
| Recons disk count | Indicates the number of disks which are currently being reconstructed. | Number | |
| Recons parity disk count | Indicates the number of parity disks which are currently being reconstructed. | Number | |
| Verify parity disk count | Indicates the number of parity disks which are currently being verified. | Number | |
| Failed disk count | Indicates the number of disks which are currently broken. | Number | |
| Spare disk count | Indicates the number of spare disks currently available. | Number | |

3.5 The NA File System Layer

Using the tests mapped to this layer, administrators can determine:




Figure 3.6: The tests associated with the NA File System layer

3.5.1 NetApp File Systems Test

This test monitors the NetApp filer's file system.

Target of the test : A NetApp filer

Agent deploying the test : An external agent

Outputs of the test : One set of results for every file system being monitored.

Configurable parameters for the test

| Parameter | Description |
|---------------|--|
| Test period | How often should the test be executed. |
| Host | The IP address of the host for which this test is to be configured. |
| SNMPPort | The port at which the monitored target exposes its SNMP MIB; the default is 161. |
| SNMPVersion | By default, the eG agent supports SNMP version 1. Accordingly, the default selection in the SNMPVersion list is v1 . However, if a different SNMP framework is in use in your environment, say SNMP v2 or v3 , then select the corresponding option from this list. |
| SNMPCommunity | The SNMP community name that the test uses to communicate with the storage. This parameter is specific to SNMP v1 and v2 only. Therefore, if the SNMPVersion chosen is v3 , then this parameter will not appear. |

| Parameter | Description |
|------------------|--|
| Username | This parameter appears only when v3 is selected as the SNMPVersion. SNMP version 3 (SNMPv3) is an extensible SNMP Framework which supplements the SNMPv2 Framework, by additionally supporting message security, access control, and remote SNMP configuration capabilities. To extract performance statistics from the MIB using the highly secure SNMP v3 protocol, the eG agent has to be configured with the required access privileges – in other words, the eG agent should connect to the MIB using the credentials of a user with access permissions to be MIB. Therefore, specify the name of such a user against this parameter. |
| Context | This parameter appears only when v3 is selected as the SNMPVersion. An SNMP context is a collection of management information accessible by an SNMP entity. An item of management information may exist in more than one context and an SNMP entity potentially has access to many contexts. A context is identified by the SNMPEngineID value of the entity hosting the management information (also called a contextEngineID) and a context name that identifies the specific context (also called a contextName). If the Username provided is associated with a context name, then the eG agent will be able to poll the MIB and collect metrics only if it is configured with the context name as well. In such cases therefore, specify the context name of the Username in the Context text box. By default, this parameter is set to <i>none</i> . |
| AuthPass | Specify the password that corresponds to the above-mentioned Username. This parameter once again appears only if the SNMPVersion selected is v3 . |
| Confirm Password | Confirm the AuthPass by retyping it here. |
| AuthType | This parameter too appears only if v3 is selected as the SNMPVersion. From the AuthType list box, choose the authentication algorithm using which SNMP v3 converts the specified username and password into a 32-bit format to ensure security of SNMP transactions. You can choose between the following options: <ul style="list-style-type: none"> • MD5 – Message Digest Algorithm • SHA – Secure Hash Algorithm |
| EncryptFlag | This flag appears only when v3 is selected as the SNMPVersion. By default, the eG agent does not encrypt SNMP requests. Accordingly, the this flag is set to No by default. To ensure that SNMP requests sent by the eG agent are encrypted, select the Yes option. |
| EncryptType | If this EncryptFlag is set to Yes , then you will have to mention the encryption type by selecting an option from the EncryptType list. SNMP v3 supports the following encryption types: |

| Parameter | Description |
|------------------|---|
| | <ul style="list-style-type: none"> DES – Data Encryption Standard AES – Advanced Encryption Standard |
| EncryptPassword | Specify the encryption password here. |
| Confirm Password | Confirm the encryption password by retying it here. |
| Timeout | Specify the duration (in seconds) within which the SNMP query executed by this test should time out in this text box. The default is 10 seconds. |
| Data Over TCP | By default, in an IT environment, all data transmission occurs over UDP. Some environments however, may be specifically configured to offload a fraction of the data traffic – for instance, certain types of data traffic or traffic pertaining to specific components – to other protocols like TCP, so as to prevent UDP overloads. In such environments, you can instruct the eG agent to conduct the SNMP data traffic related to the monitored target over TCP (and not UDP). For this, set this flag to Yes . By default, this flag is set to No . |

Measurements made by the test

| Measurement | Description | Measurement Unit | Interpretation |
|-------------------------|--|------------------|--|
| Used disk space | Indicates the total disk space that is in use in the referenced file system. | MB | |
| Free disk space | Indicates the total disk space that is free for use in the referenced file system. | MB | |
| Percent used disk space | Indicates the percentage of disk space currently in use in the referenced file system. | Percent | When the utilization of a file system approaches 100%, many applications using the partition could begin to experience failures. |
| Used inodes | Indicates the total number of inodes in use in the referenced file system. | Number | |
| Free inodes | Indicates the total number of inodes that are available for use in the referenced file system. | Number | |

| Measurement | Description | Measurement Unit | Interpretation |
|---------------------|---|------------------|--|
| Percent used inodes | Indicates the percentage of disk space currently in use based on inode counts, in the referenced file system. | Percent | If this value approaches 100%, then new files can no longer be created in the file system. |

3.5.2 NetApp File Status Test

This test monitors the inodes used by the file system of a NetApp filer device.

Target of the test : A NetApp filer

Agent deploying the test : An external agent

Outputs of the test : One set of results for every file system being monitored.

Configurable parameters for the test

| Parameter | Description |
|---------------|---|
| Test period | How often should the test be executed. |
| Host | The IP address of the host for which this test is to be configured. |
| SNMPPort | The port at which the monitored target exposes its SNMP MIB; the default is 161. |
| SNMPVersion | By default, the eG agent supports SNMP version 1. Accordingly, the default selection in the SNMPVersion list is v1 . However, if a different SNMP framework is in use in your environment, say SNMP v2 or v3 , then select the corresponding option from this list. |
| SNMPCommunity | The SNMP community name that the test uses to communicate with the storage. This parameter is specific to SNMP v1 and v2 only. Therefore, if the SNMPVersion chosen is v3 , then this parameter will not appear. |
| Username | This parameter appears only when v3 is selected as the SNMPVersion. SNMP version 3 (SNMPv3) is an extensible SNMP Framework which supplements the SNMPv2 Framework, by additionally supporting message security, access control, and remote SNMP configuration capabilities. To extract performance statistics from the MIB using the highly secure SNMP v3 protocol, the eG agent has to be configured with the required access privileges – in other words, the eG agent should connect to the MIB using the credentials of a user with access permissions to be MIB. Therefore, specify |

| Parameter | Description |
|------------------|--|
| | the name of such a user against this parameter. |
| Context | This parameter appears only when v3 is selected as the SNMPVersion. An SNMP context is a collection of management information accessible by an SNMP entity. An item of management information may exist in more than one context and an SNMP entity potentially has access to many contexts. A context is identified by the SNMPEngineID value of the entity hosting the management information (also called a contextEngineID) and a context name that identifies the specific context (also called a contextName). If the Username provided is associated with a context name, then the eG agent will be able to poll the MIB and collect metrics only if it is configured with the context name as well. In such cases therefore, specify the context name of the Username in the Context text box. By default, this parameter is set to <i>none</i> . |
| AuthPass | Specify the password that corresponds to the above-mentioned Username. This parameter once again appears only if the SNMPVersion selected is v3 . |
| Confirm Password | Confirm the AuthPass by retying it here. |
| AuthType | This parameter too appears only if v3 is selected as the SNMPVersion. From the AuthType list box, choose the authentication algorithm using which SNMP v3 converts the specified username and password into a 32-bit format to ensure security of SNMP transactions. You can choose between the following options: <ul style="list-style-type: none"> • MD5 – Message Digest Algorithm • SHA – Secure Hash Algorithm |
| EncryptFlag | This flag appears only when v3 is selected as the SNMPVersion. By default, the eG agent does not encrypt SNMP requests. Accordingly, the this flag is set to No by default. To ensure that SNMP requests sent by the eG agent are encrypted, select the Yes option. |
| EncryptType | If this EncryptFlag is set to Yes , then you will have to mention the encryption type by selecting an option from the EncryptType list. SNMP v3 supports the following encryption types: <ul style="list-style-type: none"> • DES – Data Encryption Standard • AES – Advanced Encryption Standard |
| EncryptPassword | Specify the encryption password here. |
| Confirm Password | Confirm the encryption password by retying it here. |
| Timeout | Specify the duration (in seconds) within which the SNMP query executed by this test |

| Parameter | Description |
|---------------|---|
| | should time out in this text box. The default is 10 seconds. |
| Data Over TCP | By default, in an IT environment, all data transmission occurs over UDP. Some environments however, may be specifically configured to offload a fraction of the data traffic – for instance, certain types of data traffic or traffic pertaining to specific components – to other protocols like TCP, so as to prevent UDP overloads. In such environments, you can instruct the eG agent to conduct the SNMP data traffic related to the monitored target over TCP (and not UDP). For this, set this flag to Yes . By default, this flag is set to No . |

Measurements made by the test

| Measurement | Description | Measurement Unit | Interpretation |
|-------------|---|------------------|--|
| Inodes used | Indicates the percentage of inodes currently in use by the file system. | Percent | A very high value is indicative of excessive inode utilization by a file system. |

3.6 The NA File Service Layer

The tests mapped to this layer monitor the accesses to the file system, and in the process, reveals how effective the access protocols were.



Figure 3.7: the tests associated with the NA File Service layer

3.6.1 NetApp RPC Test

This test reports the statistics related to the RPC (Remote Procedure Call) service executing on a NetApp filer. RPC is designed for network programming, allowing a program to make a subroutine call on a

remote machine.

Target of the test : A NetApp filer

Agent deploying the test : An external agent

Outputs of the test : One set of results for a NetApp filer being monitored.

Configurable parameters for the test

| Parameter | Description |
|---------------|--|
| Test period | How often should the test be executed. |
| Host | The IP address of the host for which this test is to be configured. |
| SNMPPort | The port at which the monitored target exposes its SNMP MIB; the default is 161 . |
| SNMPVersion | By default, the eG agent supports SNMP version 1. Accordingly, the default selection in the SNMPVersion list is v1 . However, if a different SNMP framework is in use in your environment, say SNMP v2 or v3 , then select the corresponding option from this list. |
| SNMPCommunity | The SNMP community name that the test uses to communicate with the storage. This parameter is specific to SNMP v1 and v2 only. Therefore, if the SNMPVersion chosen is v3 , then this parameter will not appear. |
| Username | This parameter appears only when v3 is selected as the SNMPVersion. SNMP version 3 (SNMPv3) is an extensible SNMP Framework which supplements the SNMPv2 Framework, by additionally supporting message security, access control, and remote SNMP configuration capabilities. To extract performance statistics from the MIB using the highly secure SNMP v3 protocol, the eG agent has to be configured with the required access privileges – in other words, the eG agent should connect to the MIB using the credentials of a user with access permissions to be MIB. Therefore, specify the name of such a user against this parameter. |
| Context | This parameter appears only when v3 is selected as the SNMPVersion. An SNMP context is a collection of management information accessible by an SNMP entity. An item of management information may exist in more than one context and an SNMP entity potentially has access to many contexts. A context is identified by the SNMPEngineID value of the entity hosting the management information (also called a contextEngineID) and a context name that identifies the specific context (also called a contextName). If the Username provided is associated with a context name, then the eG agent will be able to poll the MIB and collect metrics only if it is configured with the context name as well. In such cases therefore, specify the context name of the Username in the Context text box. By default, this parameter is set to <i>none</i> . |

| Parameter | Description |
|------------------|---|
| AuthPass | Specify the password that corresponds to the above-mentioned Username. This parameter once again appears only if the SNMPVersion selected is v3 . |
| Confirm Password | Confirm the AuthPass by retyping it here. |
| AuthType | This parameter too appears only if v3 is selected as the SNMPVersion. From the AuthType list box, choose the authentication algorithm using which SNMP v3 converts the specified username and password into a 32-bit format to ensure security of SNMP transactions. You can choose between the following options: <ul style="list-style-type: none"> • MD5 – Message Digest Algorithm • SHA – Secure Hash Algorithm |
| EncryptFlag | This flag appears only when v3 is selected as the SNMPVersion. By default, the eG agent does not encrypt SNMP requests. Accordingly, the this flag is set to No by default. To ensure that SNMP requests sent by the eG agent are encrypted, select the Yes option. |
| EncryptType | If this EncryptFlag is set to Yes , then you will have to mention the encryption type by selecting an option from the EncryptType list. SNMP v3 supports the following encryption types: <ul style="list-style-type: none"> • DES – Data Encryption Standard • AES – Advanced Encryption Standard |
| EncryptPassword | Specify the encryption password here. |
| Confirm Password | Confirm the encryption password by retyping it here. |
| Timeout | Specify the duration (in seconds) within which the SNMP query executed by this test should time out in this text box. The default is 10 seconds. |
| Data Over TCP | By default, in an IT environment, all data transmission occurs over UDP. Some environments however, may be specifically configured to offload a fraction of the data traffic – for instance, certain types of data traffic or traffic pertaining to specific components – to other protocols like TCP, so as to prevent UDP overloads. In such environments, you can instruct the eG agent to conduct the SNMP data traffic related to the monitored target over TCP (and not UDP). For this, set this flag to Yes . By default, this flag is set to No . |

Measurements made by the test

| Measurement | Description | Measurement Unit | Interpretation |
|------------------------|---|------------------|----------------|
| Call rate | Indicates the rate of RPC calls received. | Calls/Sec | |
| Bad call rate | Indicates the rate of calls rejected by the RPC layer. | Calls/Sec | |
| Percent bad calls | Indicates the percentage of calls rejected by the RPC layer. | Percent | |
| Null call receive rate | Indicates the rate at which RPC calls were not available for reception. | Calls/Sec | |
| Bad length call rate | Indicates the rate at which RPC calls with a length shorter than a minimum-sized RPC call, were received. | Calls/Sec | |
| Xdr failed call rate | Indicates the rate at which RPC calls with a header that could not be XDR decoded, were received. | Calls/Sec | |

3.6.2 NetApp NFS Test

This test reports the statistics related to the NFS (Network File System) service executing on a NetApp filer.

Target of the test : A NetApp filer

Agent deploying the test : An external agent

Outputs of the test : One set of results for a NetApp filer being monitored.

Configurable parameters for the test

| Parameter | Description |
|-------------|--|
| Test period | How often should the test be executed. |

| Parameter | Description |
|------------------|--|
| Host | The IP address of the host for which this test is to be configured. |
| SNMPPort | The port at which the monitored target exposes its SNMP MIB; the default is 161 . |
| SNMPVersion | By default, the eG agent supports SNMP version 1. Accordingly, the default selection in the SNMPVersion list is v1 . However, if a different SNMP framework is in use in your environment, say SNMP v2 or v3 , then select the corresponding option from this list. |
| SNMPCommunity | The SNMP community name that the test uses to communicate with the storage. This parameter is specific to SNMP v1 and v2 only. Therefore, if the SNMPVersion chosen is v3 , then this parameter will not appear. |
| Username | This parameter appears only when v3 is selected as the SNMPVersion. SNMP version 3 (SNMPv3) is an extensible SNMP Framework which supplements the SNMPv2 Framework, by additionally supporting message security, access control, and remote SNMP configuration capabilities. To extract performance statistics from the MIB using the highly secure SNMP v3 protocol, the eG agent has to be configured with the required access privileges – in other words, the eG agent should connect to the MIB using the credentials of a user with access permissions to be MIB. Therefore, specify the name of such a user against this parameter. |
| Context | This parameter appears only when v3 is selected as the SNMPVersion. An SNMP context is a collection of management information accessible by an SNMP entity. An item of management information may exist in more than one context and an SNMP entity potentially has access to many contexts. A context is identified by the SNMPEngineID value of the entity hosting the management information (also called a contextEngineID) and a context name that identifies the specific context (also called a contextName). If the Username provided is associated with a context name, then the eG agent will be able to poll the MIB and collect metrics only if it is configured with the context name as well. In such cases therefore, specify the context name of the Username in the Context text box. By default, this parameter is set to <i>none</i> . |
| AuthPass | Specify the password that corresponds to the above-mentioned Username. This parameter once again appears only if the SNMPVersion selected is v3 . |
| Confirm Password | Confirm the AuthPass by retying it here. |
| AuthType | This parameter too appears only if v3 is selected as the SNMPVersion. From the AuthType list box, choose the authentication algorithm using which SNMP v3 converts the specified username and password into a 32-bit format to ensure security of SNMP transactions. You can choose between the following options: <ul style="list-style-type: none"> • MD5 – Message Digest Algorithm |

| Parameter | Description |
|------------------|---|
| | <ul style="list-style-type: none"> SHA – Secure Hash Algorithm |
| EncryptFlag | This flag appears only when v3 is selected as the SNMPVersion . By default, the eG agent does not encrypt SNMP requests. Accordingly, the this flag is set to No by default. To ensure that SNMP requests sent by the eG agent are encrypted, select the Yes option. |
| EncryptType | If this EncryptFlag is set to Yes , then you will have to mention the encryption type by selecting an option from the EncryptType list. SNMP v3 supports the following encryption types: <ul style="list-style-type: none"> DES – Data Encryption Standard AES – Advanced Encryption Standard |
| EncryptPassword | Specify the encryption password here. |
| Confirm Password | Confirm the encryption password by retyping it here. |
| Timeout | Specify the duration (in seconds) within which the SNMP query executed by this test should time out in this text box. The default is 10 seconds. |
| Data Over TCP | By default, in an IT environment, all data transmission occurs over UDP. Some environments however, may be specifically configured to offload a fraction of the data traffic – for instance, certain types of data traffic or traffic pertaining to specific components – to other protocols like TCP, so as to prevent UDP overloads. In such environments, you can instruct the eG agent to conduct the SNMP data traffic related to the monitored target over TCP (and not UDP). For this, set this flag to Yes . By default, this flag is set to No . |

Measurements made by the test

| Measurement | Description | Measurement Unit | Interpretation |
|-------------------|--|------------------|----------------|
| Call rate | Indicates the rate of NFS calls received. | Calls/Sec | |
| Bad call rate | Indicates the rate of calls rejected by the NFS layer. | Calls/Sec | |
| Percent bad calls | Indicates the percentage of NFS calls rejected by the NFS layer. | Percent | |

3.6.3 NetApp CIFS Test

This test reports the statistics related to the CIFS (Common Internet File System) service executing on a NetApp filer.

Target of the test : A NetApp filer

Agent deploying the test : An external agent

Outputs of the test : One set of results for a NetApp filer being monitored.

Configurable parameters for the test

| Parameter | Description |
|---------------|---|
| Test period | How often should the test be executed. |
| Host | The IP address of the host for which this test is to be configured. |
| SNMPPort | The port at which the monitored target exposes its SNMP MIB; the default is 161. |
| SNMPVersion | By default, the eG agent supports SNMP version 1. Accordingly, the default selection in the SNMPVersion list is v1 . However, if a different SNMP framework is in use in your environment, say SNMP v2 or v3 , then select the corresponding option from this list. |
| SNMPCommunity | The SNMP community name that the test uses to communicate with the storage. This parameter is specific to SNMP v1 and v2 only. Therefore, if the SNMPVersion chosen is v3 , then this parameter will not appear. |
| Username | This parameter appears only when v3 is selected as the SNMPVersion. SNMP version 3 (SNMPv3) is an extensible SNMP Framework which supplements the SNMPv2 Framework, by additionally supporting message security, access control, and remote SNMP configuration capabilities. To extract performance statistics from the MIB using the highly secure SNMP v3 protocol, the eG agent has to be configured with the required access privileges – in other words, the eG agent should connect to the MIB using the credentials of a user with access permissions to be MIB. Therefore, specify the name of such a user against this parameter. |
| Context | This parameter appears only when v3 is selected as the SNMPVersion. An SNMP context is a collection of management information accessible by an SNMP entity. An item of management information may exist in more than one context and an SNMP entity potentially has access to many contexts. A context is identified by the SNMPEngineID value of the entity hosting the management information (also called a contextEngineID) and a context name that identifies the specific context (also called a |

| Parameter | Description |
|------------------|---|
| | contextName). If the Username provided is associated with a context name, then the eG agent will be able to poll the MIB and collect metrics only if it is configured with the context name as well. In such cases therefore, specify the context name of the Username in the Context text box. By default, this parameter is set to none . |
| AuthPass | Specify the password that corresponds to the above-mentioned Username. This parameter once again appears only if the SNMPVersion selected is v3 . |
| Confirm Password | Confirm the AuthPass by retyping it here. |
| AuthType | This parameter too appears only if v3 is selected as the SNMPVersion. From the AuthType list box, choose the authentication algorithm using which SNMP v3 converts the specified username and password into a 32-bit format to ensure security of SNMP transactions. You can choose between the following options: <ul style="list-style-type: none"> • MD5 – Message Digest Algorithm • SHA – Secure Hash Algorithm |
| EncryptFlag | This flag appears only when v3 is selected as the SNMPVersion. By default, the eG agent does not encrypt SNMP requests. Accordingly, the this flag is set to No by default. To ensure that SNMP requests sent by the eG agent are encrypted, select the Yes option. |
| EncryptType | If this EncryptFlag is set to Yes , then you will have to mention the encryption type by selecting an option from the EncryptType list. SNMP v3 supports the following encryption types: <ul style="list-style-type: none"> • DES – Data Encryption Standard • AES – Advanced Encryption Standard |
| EncryptPassword | Specify the encryption password here. |
| Confirm Password | Confirm the encryption password by retyping it here. |
| Timeout | Specify the duration (in seconds) within which the SNMP query executed by this test should time out in this text box. The default is 10 seconds. |
| Data Over TCP | By default, in an IT environment, all data transmission occurs over UDP. Some environments however, may be specifically configured to offload a fraction of the data traffic – for instance, certain types of data traffic or traffic pertaining to specific components – to other protocols like TCP, so as to prevent UDP overloads. In such environments, you can instruct the eG agent to conduct the SNMP data traffic related to the monitored target over TCP (and not UDP). For this, set this flag to Yes . By default, this flag is set to No . |

Measurements made by the test

| Measurement | Description | Measurement Unit | Interpretation |
|-----------------|---|------------------|----------------|
| Connected users | Indicates the current number of CIFS users on the filer. | Number | |
| Active sessions | Indicates the current number of active CIFS sessions on the filer. | Number | |
| Operation rate | Indicates the number of CIFS operations done by the filer, since the last time the statistics were cleared. | Operations/Sec | |
| Call rate | Indicates the rate at which CIFS calls were received. | Calls/Sec | |
| Bad call rate | Indicates the rate at which CIFS calls were rejected | Calls/Sec | |
| Read rate | Indicates the rate at which CIFS read operations were performed on a file or directory. | Percent | |
| Write rate | The rate at which CIFS write operations were performed on a file or directory | Writes/Sec | |

About eG Innovations

eG Innovations provides intelligent performance management solutions that automate and dramatically accelerate the discovery, diagnosis, and resolution of IT performance issues in on-premises, cloud and hybrid environments. Where traditional monitoring tools often fail to provide insight into the performance drivers of business services and user experience, eG Innovations provides total performance visibility across every layer and every tier of the IT infrastructure that supports the business service chain. From desktops to applications, from servers to network and storage, from virtualization to cloud, eG Innovations helps companies proactively discover, instantly diagnose, and rapidly resolve even the most challenging performance and user experience issues.

eG Innovations is dedicated to helping businesses across the globe transform IT service delivery into a competitive advantage and a center for productivity, growth and profit. Many of the world's largest businesses use eG Enterprise to enhance IT service performance, increase operational efficiency, ensure IT effectiveness and deliver on the ROI promise of transformational IT investments across physical, virtual and cloud environments.

To learn more visit www.eginnovations.com.

Contact Us

For support queries, email support@eginnovations.com.

To contact eG Innovations sales team, email sales@eginnovations.com.

Copyright © 2018 eG Innovations Inc. All rights reserved.

This document may not be reproduced by any means nor modified, decompiled, disassembled, published or distributed, in whole or in part, or translated to any electronic medium or other means without the prior written consent of eG Innovations. eG Innovations makes no warranty of any kind with regard to the software and documentation, including, but not limited to, the implied warranties of merchantability and fitness for a particular purpose. The information contained in this document is subject to change without notice.

All right, title, and interest in and to the software and documentation are and shall remain the exclusive property of eG Innovations. All trademarks, marked and not marked, are the property of their respective owners. Specifications subject to change without notice.