



Monitoring EMC CLARiiON

eG Enterprise v6

Restricted Rights Legend

The information contained in this document is confidential and subject to change without notice. No part of this document may be reproduced or disclosed to others without the prior permission of eG Innovations Inc. eG Innovations Inc. makes no warranty of any kind with regard to the software and documentation, including, but not limited to, the implied warranties of merchantability and fitness for a particular purpose.

Trademarks

Microsoft Windows, Windows NT, Windows 2000, Windows 2003 and Windows 2008 are either registered trademarks or trademarks of Microsoft Corporation in United States and/or other countries.

The names of actual companies and products mentioned herein may be the trademarks of their respective owners.

Copyright

©2015 eG Innovations Inc. All rights reserved.

Table of Contents

MONITORING THE EMC CLARIION	1
1.1 Pre-requisites for Monitoring EMC CLARiiON	2
1.1.1 General Pre-requisites	2
1.1.2 Pre-requisites for Monitoring Using the NaviSphere Management Suite	2
1.1.3 Pre-requisites for Monitoring Using EMC's SMI-S Provider.....	7
1.2 The EMC Hardware Layer.....	9
1.2.1 Clariion CRUs Test	9
1.2.2 Clariion Fault Hardware Test	11
1.2.3 Clariion Disk Array Enclosures Test	13
1.3 The Network Layer.....	17
1.4 The EMC Physical Disks Layer.....	18
1.4.1 Clariion Disks Test.....	18
1.4.2 EMC RAID Disks Test	23
1.5 The EMC Disk Pools Layer	30
1.5.1 Clariion RAID Groups Test.....	31
1.6 The EMC Luns Layer.....	37
1.6.1 Clariion LUNs Test	37
1.6.2 EMC RAID LUNs Test.....	44
1.7 The EMC Cache Layer.....	51
1.7.1 Clariion Cache Test	52
1.8 The EMC Storage Processor Layer	59
1.8.1 Clariion Storage Ports Test	60
1.8.2 Clariion Storage Processors Test.....	63
1.8.3 EMC RAID Arrays Test	66
1.8.4 EMC RAID System Test	73
1.9 EMC HBA Layer	80
1.9.1 Clariion HBA Ports Test	81
CONCLUSION	85

Table of Figures

Figure 1.1: The layer model of the EMC CLARiiion device	1
Figure 1.2: Setting verification level	3
Figure 1.3: Logging into the Navisphere Express Console	4
Figure 1.4: The Navisphere Express Console.....	4
Figure 1.5: The System Services section.....	5
Figure 1.6: The Diagnostic Files page	5
Figure 1.7: Scrolling down the Diagnostic Files pages to view the Performance Logs button	6
Figure 1.8: Starting data logging	6
Figure 1.9: Configuring data logging.....	7
Figure 1.10: Reviewing data logging specifications.....	7
Figure 1.11: The test associated with the Hardware layer	9
Figure 1.12: The test mapped to the EMC Network layer	17
Figure 1.13: The test mapped to the EMC Physical Disks layer	18
Figure 1.14: The detailed diagnosis of the LUNs measure	23
Figure 1.15: The tests mapped to the EMC Disk Pools layer.....	31
Figure 1.16: The detailed diagnosis of the Disk count measure	37
Figure 1.17: The detailed diagnosis of the LUN count measure	37
Figure 1.18: The test mapped to the EMC Luns layer	37
Figure 1.19: The detailed diagnosis of the State measure	43
Figure 1.20: The EMS Cache Layer	52
Figure 1.21: The tests mapped to the EMC Storage Processor layer	60
Figure 1.22: The test mapped to the EMC HBAs layer	81
Figure 1.23: The detailed diagnosis of the Logged in measure	84

Chapter

1

Monitoring the EMC CLARiiON

EMC CLARiiON leads the midrange storage market in providing customers with cost-effective storage solutions that deliver the highest levels of performance, functionality, and reliability.

CLARiiON is ideal for today's mid-sized enterprises as it can scale system capacity and performance, simplify management, and can protect critical applications and data.

This implies that even the slightest of deficiencies in the performance of the server if not detected promptly and resolved quickly, can result in irredeemable loss of critical data. To avoid such an adversity, the EMC CLARiiON storage solution should be monitored 24 x 7.

eG Enterprise offers a specialized *EMC Clariion SAN* monitoring model that monitors the core functions and components of the CLARiiON storage device, and proactively alerts administrators to issues in its overall performance and its critical operations, so that the holes are plugged before any data loss occurs.




Figure 1.1: The layer model of the EMC CLARiiON device

Each layer of this model is mapped to tests that monitor a critical component of the device such as the disks, the LUNs, the storage processors, etc. To collect the required metrics from the device, the eG agent uses the following mechanisms:

- By default, eG uses the command line utility (**NaviSecCLI.exe**) available as part of the **NaviSphere Management Suite** of EMC CLARiiON for monitoring it. The **NaviSphere Management Suite** is the central

console using which the CLARIION environment can be controlled and monitored. The **NaviSphere CLI** (i.e., the **NaviSecCLI.exe**) is used for issuing commands to an array, writing scripts, requesting array status, and as a tool for problem determination.

- Optionally, you can also configure the eG agent to use the SMI-S provider of EMC CLARIION to collect additional performance metrics from the storage device.

1.1 Pre-requisites for Monitoring EMC CLARIION

The sections below detail the pre-requisites for monitoring EMC CLARIION.

1.1.1 General Pre-requisites

- To enable the eG agent to use both the **NaviSphere CLI** and the SMI-S provider for collecting metrics from EMC CLARIION, you need to make sure that both the CLI and the provider are installed on the same host.

1.1.2 Pre-requisites for Monitoring Using the NaviSphere Management Suite

To enable the eG agent to use the **NaviSphere Management Suite** to collect metrics from CLARIION, the following pre-requisites should be fulfilled:

1. If the storage device is SSL-enabled, then, when installing the **NaviSphere CLI**, make sure that the **Verification Level** is set to **Low** (see Figure 1.1). This ensures that the SSL certificate sent by the storage array is not verified by the CLI.




Figure 1.2: Setting verification level

2. The eG agent should be deployed on the same host on which the **NaviSphere CLI** (i.e., the **NaviSecCLI.exe**) operates;
3. The **NaviSphere CLI** should run on a host that communicates with the storage system;
4. The tests that use the NaviSphere CLI should be configured with the full path to the **NaviSecCLI.exe** and the credentials of a user who has access to the storage system.
5. Performance logging should be enabled on the storage system; the steps to be followed to achieve this have been detailed in Section 1.1.2.1 of this document.

1.1.2.1 Enabling Performance Logging on the Storage System

To achieve this, login to the host on which the **Navisphere CLI** operates, and issue the following command at the command prompt:

```
naviseccli -h <array-ip> -scope 0 -user <name of user with access to storage system> -password <password of user with access to storage system> setstats -on
```

For instance, if the IP address of the storage array is **192.168.10.86**, and the credentials of the user with rights to access the storage array are **username: john** and **password: john**, the command will be:

```
naviseccli -h 19.168.10.86 -scope 0 -user john -password john setstats -on
```

Alternatively, you can follow the steps detailed below to enable performance logging on the storage system:

1. From a web browser, connect to the storage array using the URL: **Error! Hyperlink reference not valid.**

2. Figure 1.3 will then appear prompting you to login to the **Navisphere Express Console**. Provide the credentials of the SAN administrator against **User name** and **Password**, and click the **Login** button to login.



Figure 1.3: Logging into the Navisphere Express Console

3. The **Navisphere Express Console** will then appear, as depicted by Figure 1.4.




Figure 1.4: The Navisphere Express Console

4. From the list of options provided in the left panel of Figure 1.4, select the **Services** option under the **System** head (as indicated by Figure 1.4).
5. A **System Services** page will then appear in the right panel (see Figure 1.5). Click on the **Diagnostic Files** button in Figure 1.5.




Figure 1.5: The System Services section

- When the **Diagnostic Files** page appears (see Figure 1.6), scroll down the page to view the **Performance Logs** button (see Figure 1.7). Click on this button.




Figure 1.6: The Diagnostic Files page




Figure 1.7: Scrolling down the Diagnostic Files pages to view the Performance Logs button

7. In the **Performance Logs** page that then appears (see Figure 1.8), click on the **Start** button to begin data logging.




Figure 1.8: Starting data logging

8. You can configure how frequently data logging should occur and also indicate when it should stop using the **Polling interval** and **Stop Logging** in controls (respectively) in Figure 1.9 that appears. Then, click the **Start Logging** button in Figure 1.9 to begin data logging.




Figure 1.9: Configuring data logging

9. Figure 1.10 then appears where you can review your data logging specifications.




Figure 1.10: Reviewing data logging specifications

1.1.3 Pre-requisites for Monitoring Using EMC's SMI-S Provider

By default, the tests that use the SMI-S provider of EMC to collect metrics are disabled for the *EMC Clariion SAN* component. If one/more of these tests are enabled, you need to do the following to make sure that those tests run and report metrics:

- If you want the eG agent to use the SMI-S provider too for metrics collection, then, you need to make sure that you manage the target EMC CLARiiON device in the eG admin interface using the **Host IP/Name** of that host on which the provider has been installed.
- The tests that use the SMI-S Provider for collecting metrics should be configured with the following:
 - **THE SERIAL NUMBER** of the storage device to be monitored.

This is because, the proxy implementation of the provider can manage multiple devices at the same time. The **SERIAL NUMBER** is the unique identifier that will enable the eG agent to collect metrics from the right storage device.

- Credentials of an SMI-S provider CIM user who has the right to access the storage device, execute API commands on it and pull out the desired metrics
For monitoring EMC CLARiiON, you will have to provide the credentials of a user who has been assigned the **Monitor** role.
- The namespace that uniquely identifies the profiles specific to the SMI-S provider in use.

Once the aforesaid pre-requisites are fulfilled, the eG agent will extract useful statistics from the storage system and report it to the eG manager.

Using these metrics, the following critical performance queries can be answered:

- Are there any faulty components on the storage system? If so, which components are these?
- Does the storage system support any invalid CRUs (Customer Replaceable Units)?
- Are any RAID groups invalid?
- Do all RAID groups have sufficient disk space? Is any RAID group experiencing a space crunch?
- Is any RAID group being defragmented or expanded?
- Is the defragmentation / expansion priority 'High' for any RAID group?
- Is I/O load balanced across all LUNS?
- Is any LUN being rebuilt?
- Is any LUN being bound? If so, what is the status of the binding process?
- Is there sufficient space in the disks?
- Are the disks processing requests quickly?
- Is any disk experiencing too many read/write retries?
- Is load uniformly distributed across disks?
- Is any disk in the disabled state?
- Is any disk running out of space currently?
- Are any disks experiencing too many hard read/write or soft read/write errors?
- Are there any error-prone LUNs?
- Are the read/write caches of Storage Processors A and B enabled?
- Are the read/write caches of Storage Processors A and B correctly sized? Have adequate memory pages not been allotted to any cache? If so, which cache is it (read/write), and which storage processor is that cache associated with?

- Is any cache been under-utilized?
- Is any storage port link down?
- Is any storage processor in a faulty state now?
- Is any storage processor overloaded?
- Is any HBA port not plugged into the fibre channel?
- Which HBA ports are not trusted?
- Which HBA ports are not defined?

The sections that will follow discuss each of the layers of Figure 1.1 in great detail.

1.2 The EMC Hardware Layer

Using the test mapped to this layer, you can proactively capture the potential failure of the core hardware components of the Clariion disk array enclosure.



Figure 1.11: The test associated with the Hardware layer

1.2.1 Clariion CRUs Test

A Customer Replaceable Unit (CRU) is a part or subassembly designed so that an end-user or customer can easily replace a failing part or subassembly where it is located.

This test auto-discovers the CRUs supported by a Clariion storage system, and reports the current state of each, so that potential failures are swiftly detected and the affected components replaced before any permanent damage occurs.

Purpose	Auto-discovers the CRUs supported by a Clariion storage system, and reports the current state
---------	---

	of each			
Target of the test	An EMC CLARiiON storage device			
Agent deploying the test	A remote agent			
Configurable parameters for the test	<ol style="list-style-type: none"> TESTPERIOD – How often should the test be executed HOST – The IP address of the storage device PORT - The port number at which the storage device listens. The default is NULL. CLARIION IP - By default, the host IP will be displayed here. If the eG agent has also been configured to use the SMI-S provider for metrics collection, then the IP address of host on which the SMI-S provider has been installed, will be displayed here by default. In this case, you should change the value of this parameter to reflect the IP address of the EMC CLARiiON storage device. However, if the eG agent uses only the NaviSphere CLI for monitoring, then the default settings can remain. NAVISECCLIPATH - The eG agent uses the command-line utility, NaviSecCli.exe, which is part of the NaviSphere Management Suite, to communicate with and monitor the storage device. To enable the eG agent to invoke the CLI, configure the full path to the CLI in the NAVISECCLIPATH text box. USER NAME and PASSWORD - Provide the credentials of a user who is authorized to access the storage device in the user name and password text boxes. CONFIRM PASSWORD - Confirm the password by retyping it here. TIMEOUT - Indicate the duration (in seconds) for which this test should wait for a response from the storage device. By default, this is set to 120 seconds. Note that the 'TIMEOUT' value should always be set between 3 and 600 seconds only. 			
Outputs of the test	One set of results for each CRU on the storage device			
Measurements made by the	<table border="1"> <thead> <tr> <th>Measurement</th> <th>Measurement Unit</th> <th>Interpretation</th> </tr> </thead> </table>	Measurement	Measurement Unit	Interpretation
Measurement	Measurement Unit	Interpretation		

test	<p>Status: Indicates the current status of this CRU.</p>	<p>This measure reports one of the following values as the status of the CRU:</p> <ul style="list-style-type: none"> a. Invalid b. Present c. N/A d. Empty <p>The numeric values that correspond to each of the states discussed above are as follows:</p> <table border="1" data-bbox="889 629 1421 868"> <thead> <tr> <th data-bbox="889 629 1139 671">Value</th><th data-bbox="1139 629 1421 671">State</th></tr> </thead> <tbody> <tr> <td data-bbox="889 671 1139 713">0</td><td data-bbox="1139 671 1421 713">Invalid</td></tr> <tr> <td data-bbox="889 713 1139 756">1</td><td data-bbox="1139 713 1421 756">Present</td></tr> <tr> <td data-bbox="889 756 1139 798">2</td><td data-bbox="1139 756 1421 798">N/A</td></tr> <tr> <td data-bbox="889 798 1139 868">3</td><td data-bbox="1139 798 1421 868">Empty</td></tr> </tbody> </table> <p>Note: By default, this measure reports the States listed in the table above to indicate the status of a CRU. The graph of this measure however, represents the CRU state using the numeric equivalents - <i>0 to 3</i>.</p>	Value	State	0	Invalid	1	Present	2	N/A	3	Empty
Value	State											
0	Invalid											
1	Present											
2	N/A											
3	Empty											

1.2.2 Clariion Fault Hardware Test

This test promptly alerts administrators to faulty components on the storage system. You can use the detailed diagnosis of this test to view which components are faulty.

Purpose	Promptly alerts administrators to faulty components on the storage system
Target of the test	An EMC CLARiON storage device
Agent deploying the test	A remote agent

Configurable parameters for the test	<ol style="list-style-type: none"> 1. TESTPERIOD – How often should the test be executed 2. HOST – The IP address of the storage device 3. PORT - The port number at which the storage device listens. The default is NULL. 4. CLARIION IP - By default, the host IP will be displayed here. If the eG agent has also been configured to use the SMI-S provider for metrics collection, then the IP address of host on which the SMI-S provider has been installed, will be displayed here by default. In this case, you should change the value of this parameter to reflect the IP address of the EMC CLARIION storage device. However, if the eG agent uses only the NaviSphere CLI for monitoring, then the default settings can remain. 5. NAVISECCLIPATH - The eG agent uses the command-line utility, NaviSecCli.exe, which is part of the NaviSphere Management Suite, to communicate with and monitor the storage device. To enable the eG agent to invoke the CLI, configure the full path to the CLI in the NAVISECCLIPATH text box. 6. USER NAME and PASSWORD - Provide the credentials of a user who is authorized to access the storage device in the user name and password text boxes. 7. CONFIRM PASSWORD - Confirm the password by retyping it here. 8. TIMEOUT - Indicate the duration (in seconds) for which this test should wait for a response from the storage device. By default, this is set to 120 seconds. Note that the 'TIMEOUT' value should always be set between 3 and 600 seconds only. 9. DETAILED DIAGNOSIS - To make diagnosis more efficient and accurate, the eG Enterprise suite embeds an optional detailed diagnostic capability. With this capability, the eG agents can be configured to run detailed, more elaborate tests as and when specific problems are detected. To enable the detailed diagnosis capability of this test for a particular server, choose the On option. To disable the capability, click on the Off option. <p>The option to selectively enable/disable the detailed diagnosis capability will be available only if the following conditions are fulfilled:</p> <ul style="list-style-type: none"> ➤ The eG manager license should allow the detailed diagnosis capability ➤ Both the normal and abnormal frequencies configured for the detailed diagnosis measures should not be 0. 		
Outputs of the test	One set of results for the storage device being monitored		
Measurements made by the	Measurement	Measurement Unit	Interpretation

test	<p>Faulted: Indicates whether any component on the device is currently faulty or not.</p>	<p>This measure reports the value <i>Yes</i> if at least one component on the storage system has been found to be faulty. The value <i>No</i> is reported if no faulty components have been discovered on the storage system.</p> <p>The numeric values that correspond to each of the fault states discussed above are as follows:</p> <table border="1" data-bbox="889 481 1421 629"> <thead> <tr> <th data-bbox="889 481 1144 523">Numeric Value</th><th data-bbox="1144 481 1421 523">State</th></tr> </thead> <tbody> <tr> <td data-bbox="889 523 1144 566">0</td><td data-bbox="1144 523 1421 566">Yes</td></tr> <tr> <td data-bbox="889 566 1144 629">1</td><td data-bbox="1144 566 1421 629">No</td></tr> </tbody> </table> <p>Note: By default, this measure reports the States listed in the table above to indicate the fault status of a component. The graph of this measure however, represents the fault state using the numeric equivalents - <i>0</i> and <i>1</i>. If this measure reports the value <i>Yes</i>, then, you can use the detailed diagnosis of the measure to know which components on the system are currently faulty.</p>	Numeric Value	State	0	Yes	1	No
Numeric Value	State							
0	Yes							
1	No							

1.2.3 Clariion Disk Array Enclosures Test

This test reveals the status of the hardware components of the disk array enclosure, such as, the fans, the power supply units, and the LCC. Potential hardware failures in the enclosure can be proactively determined with the help of this test.

This test is disabled by default. To enable the test, go to the **ENABLE / DISABLE TESTS** page using the menu sequence : Agents -> Tests -> Enable/Disable, pick *EMC Clariion SAN* as the **Component type**, set *Performance* as the **Test type**, choose the test from the **DISABLED TESTS** list, and click on the **>>** button to move the test to the **ENABLED TESTS** list. Finally, click the **Update** button.

Purpose	Reveals the status of the hardware components of the disk array enclosure, such as, the fans, the power supply units, and the LCC
Target of the test	An EMC CLARiON storage device
Agent deploying the test	A remote agent

Configurable parameters for the test	<ol style="list-style-type: none"> 1. TESTPERIOD – How often should the test be executed 2. HOST – The IP address of the storage device 3. PORT - The port number at which the storage device listens. The default is NULL. 4. CLARIION IP - By default, the host IP will be displayed here. If the eG agent has also been configured to use the SMI-S provider for metrics collection, then the IP address of host on which the SMI-S provider has been installed, will be displayed here by default. In this case, you should change the value of this parameter to reflect the IP address of the EMC CLARIION storage device. However, if the eG agent uses only the NaviSphere CLI for monitoring, then the default settings can remain. 5. NAVISECCLIPATH - The eG agent uses the command-line utility, NaviSecCli.exe, which is part of the NaviSphere Management Suite, to communicate with and monitor the storage device. To enable the eG agent to invoke the CLI, configure the full path to the CLI in the NAVISECCLIPATH text box. 6. USER NAME and PASSWORD - Provide the credentials of a user who is authorized to access the storage device in the user name and password text boxes. 7. CONFIRM PASSWORD - Confirm the password by retyping it here. 8. TIMEOUT - Indicate the duration (in seconds) for which this test should wait for a response from the storage device. By default, this is set to 120 seconds. Note that the 'TIMEOUT' value should always be set between 3 and 600 seconds only. 												
Outputs of the test	One set of results for each disk array enclosure on the storage device												
Measurements made by the test	<table border="1" data-bbox="360 1036 1428 1478"> <thead> <tr> <th data-bbox="360 1036 649 1115">Measurement</th> <th data-bbox="649 1036 866 1115">Measurement Unit</th> <th data-bbox="866 1036 1428 1115">Interpretation</th> </tr> </thead> <tbody> <tr> <td data-bbox="360 1115 649 1478"> Fan A state: Indicates the current state of Fan A. </td><td data-bbox="649 1115 866 1478"> Status </td><td data-bbox="866 1115 1428 1478"> <p>If the fan A is unavailable, then this measure will return the value "Not Present". On the other hand, if fan A is available, then the value of this measure will be "Present".</p> <p>The numeric values that correspond to each of the states discussed above are as follows:</p> <table border="1" data-bbox="882 1332 1416 1478"> <thead> <tr> <th data-bbox="882 1332 1139 1374">Value</th> <th data-bbox="1139 1332 1416 1374">State</th> </tr> </thead> <tbody> <tr> <td data-bbox="882 1374 1139 1417">1</td> <td data-bbox="1139 1374 1416 1417">Present</td> </tr> <tr> <td data-bbox="882 1417 1139 1459">0</td> <td data-bbox="1139 1417 1416 1459">Not Present</td> </tr> </tbody> </table> </td></tr> </tbody> </table> <p>Note:</p> <p>By default, this measure reports the States listed in the table above to indicate the status of fan A. The graph of this measure however, represents the status of fan A using the numeric equivalents - 0 to 2.</p>	Measurement	Measurement Unit	Interpretation	Fan A state: Indicates the current state of Fan A.	Status	<p>If the fan A is unavailable, then this measure will return the value "Not Present". On the other hand, if fan A is available, then the value of this measure will be "Present".</p> <p>The numeric values that correspond to each of the states discussed above are as follows:</p> <table border="1" data-bbox="882 1332 1416 1478"> <thead> <tr> <th data-bbox="882 1332 1139 1374">Value</th> <th data-bbox="1139 1332 1416 1374">State</th> </tr> </thead> <tbody> <tr> <td data-bbox="882 1374 1139 1417">1</td> <td data-bbox="1139 1374 1416 1417">Present</td> </tr> <tr> <td data-bbox="882 1417 1139 1459">0</td> <td data-bbox="1139 1417 1416 1459">Not Present</td> </tr> </tbody> </table>	Value	State	1	Present	0	Not Present
Measurement	Measurement Unit	Interpretation											
Fan A state: Indicates the current state of Fan A.	Status	<p>If the fan A is unavailable, then this measure will return the value "Not Present". On the other hand, if fan A is available, then the value of this measure will be "Present".</p> <p>The numeric values that correspond to each of the states discussed above are as follows:</p> <table border="1" data-bbox="882 1332 1416 1478"> <thead> <tr> <th data-bbox="882 1332 1139 1374">Value</th> <th data-bbox="1139 1332 1416 1374">State</th> </tr> </thead> <tbody> <tr> <td data-bbox="882 1374 1139 1417">1</td> <td data-bbox="1139 1374 1416 1417">Present</td> </tr> <tr> <td data-bbox="882 1417 1139 1459">0</td> <td data-bbox="1139 1417 1416 1459">Not Present</td> </tr> </tbody> </table>	Value	State	1	Present	0	Not Present					
Value	State												
1	Present												
0	Not Present												

	<p>Fan B state: Indicates the current state of Fan B.</p>	Status	<p>If fan B is unavailable, then this measure will return the value "Not Present". On the other hand, if fan B is available, then the value of this measure will be "Present".</p> <p>The numeric values that correspond to each of the states discussed above are as follows:</p> <table border="1" data-bbox="887 445 1421 593"> <thead> <tr> <th>Value</th><th>State</th></tr> </thead> <tbody> <tr> <td>1</td><td>Present</td></tr> <tr> <td>0</td><td>Not Present</td></tr> </tbody> </table> <p>Note:</p> <p>By default, this measure reports the values <i>Present</i> or <i>Not Present</i> to indicate the status of fan B. The graph of this measure however, represents the status of fan A using the numeric equivalents - <i>0</i> or <i>1</i>.</p>	Value	State	1	Present	0	Not Present
Value	State								
1	Present								
0	Not Present								
	<p>Power A state: Indicates the current state of the power supply unit A.</p>	Status	<p>If power unit A is unavailable, then this measure will return the value "Not Present". On the other hand, if power unit A is available, then the value of this measure will be "Present".</p> <p>The numeric values that correspond to each of the states discussed above are as follows:</p> <table border="1" data-bbox="887 1079 1421 1227"> <thead> <tr> <th>Value</th><th>State</th></tr> </thead> <tbody> <tr> <td>1</td><td>Present</td></tr> <tr> <td>0</td><td>Not Present</td></tr> </tbody> </table> <p>Note:</p> <p>By default, this measure reports the values <i>Present</i> or <i>Not Present</i> to indicate the status of power supply unit A. The graph of this measure however, represents the status of unit A using the numeric equivalents - <i>0</i> or <i>1</i>.</p>	Value	State	1	Present	0	Not Present
Value	State								
1	Present								
0	Not Present								

	<p>Power B state: Indicates the current state of the power supply unit B.</p>	Status	<p>If power unit B is unavailable, then this measure will return the value "Not Present". On the other hand, if power unit B is available, then the value of this measure will be "Present".</p> <p>The numeric values that correspond to each of the states discussed above are as follows:</p> <table border="1"> <thead> <tr> <th data-bbox="882 445 1090 487">Value</th><th data-bbox="1090 445 1416 487">State</th></tr> </thead> <tbody> <tr> <td data-bbox="882 487 1090 530">1</td><td data-bbox="1090 487 1416 530">Present</td></tr> <tr> <td data-bbox="882 530 1090 572">0</td><td data-bbox="1090 530 1416 572">Not Present</td></tr> </tbody> </table> <p>Note: By default, this measure reports the values <i>Present</i> or <i>Not Present</i> to indicate the status of power supply unit B. The graph of this measure however, represents the status of unit B using the numeric equivalents - <i>0</i> or <i>1</i>.</p>	Value	State	1	Present	0	Not Present
Value	State								
1	Present								
0	Not Present								
	<p>LCC A state: Indicates the current state of the LCC A.</p>	Status	<p>If LCC A is unavailable, then this measure will return the value "Not Present". On the other hand, if LCC A is available, then the value of this measure will be "Present".</p> <p>The numeric values that correspond to each of the states discussed above are as follows:</p> <table border="1"> <thead> <tr> <th data-bbox="882 1100 1090 1142">Value</th><th data-bbox="1090 1100 1416 1142">State</th></tr> </thead> <tbody> <tr> <td data-bbox="882 1142 1090 1184">1</td><td data-bbox="1090 1142 1416 1184">Present</td></tr> <tr> <td data-bbox="882 1184 1090 1227">0</td><td data-bbox="1090 1184 1416 1227">Not Present</td></tr> </tbody> </table> <p>Note: By default, this measure reports the values <i>Present</i> or <i>Not Present</i> to indicate the status of LCC A. The graph of this measure however, represents the status of LCC A using the numeric equivalents - <i>0</i> or <i>1</i>.</p>	Value	State	1	Present	0	Not Present
Value	State								
1	Present								
0	Not Present								

<p>LCC B state: Indicates the current state of the LCC B.</p>	<p>Status</p>	<p>If LCC B is unavailable, then this measure will return the value "Not Present". On the other hand, if LCC B is available, then the value of this measure will be "Present".</p> <p>The numeric values that correspond to each of the states discussed above are as follows:</p> <table border="1"> <thead> <tr> <th data-bbox="882 451 1095 487">Value</th><th data-bbox="1095 451 1421 487">State</th></tr> </thead> <tbody> <tr> <td data-bbox="1013 502 1095 538">1</td><td data-bbox="1241 502 1421 538">Present</td></tr> <tr> <td data-bbox="1013 553 1095 589">0</td><td data-bbox="1225 553 1421 589">Not Present</td></tr> </tbody> </table> <p>Note: By default, this measure reports the values <i>Present</i> or <i>Not Present</i> to indicate the status of LCC B. The graph of this measure however, represents the status of LCC B using the numeric equivalents - <i>0</i> or <i>1</i>.</p>	Value	State	1	Present	0	Not Present
Value	State							
1	Present							
0	Not Present							

1.3 The Network Layer

Monitor the availability of the Clariion storage device over the network using the test mapped to this layer.



Figure 1.12: The test mapped to the EMC Network layer

Since the test mapped to this layer has already been dealt with in the other documents, let us proceed to the next layer.

1.4 The EMC Physical Disks Layer

Instantly identify abnormal/error-prone disks on the EMC CLARiiON storage device using the test mapped to this layer.




Figure 1.13: The test mapped to the EMC Physical Disks layer

1.4.1 Clariion Disks Test

This test reveals the state, I/O activity, and overall health of each disk supported by the storage system.

Purpose	Reveals the state, I/O activity, and overall health of each disk supported by the storage system
Target of the test	An EMC CLARiiON storage device
Agent deploying the test	A remote agent

Configurable parameters for the test	<ol style="list-style-type: none"> 1. TESTPERIOD – How often should the test be executed 2. HOST – The IP address of the storage device 3. PORT - The port number at which the storage device listens. The default is NULL. 4. CLARIION IP - By default, the host IP will be displayed here. If the eG agent has also been configured to use the SMI-S provider for metrics collection, then the IP address of host on which the SMI-S provider has been installed, will be displayed here by default. In this case, you should change the value of this parameter to reflect the IP address of the EMC CLARIION storage device. However, if the eG agent uses only the NaviSphere CLI for monitoring, then the default settings can remain. 5. NAVISECCLIPATH - The eG agent uses the command-line utility, NaviSecCli.exe, which is part of the NaviSphere Management Suite, to communicate with and monitor the storage device. To enable the eG agent to invoke the CLI, configure the full path to the CLI in the NAVISECCLIPATH text box. 6. USER NAME AND PASSWORD - Provide the credentials of a user who is authorized to access the storage device in the user name and password text boxes. 7. CONFIRM PASSWORD - Confirm the password by retyping it here. 8. IGNORE DISABLED DISKS - By default, this flag is set to No, indicating that the test monitors all disks by default. Set this flag to Yes if you want the test to consider only the 'enabled' disks for monitoring. 9. EXCLUDE DISKS - Provide a comma-separated list of disk IDs that you want to exclude from the monitoring scope of this test. By default, this is set to <i>none</i> indicating that no disks are excluded by default. 10. TIMEOUT - Indicate the duration (in seconds) for which this test should wait for a response from the storage device. By default, this is set to 120 seconds. Note that the 'TIMEOUT' value should always be set between 3 and 600 seconds only. 11. DD FREQUENCY - - Refers to the frequency with which detailed diagnosis measures are to be generated for this test. The default is <i>4:1</i>. This indicates that, by default, detailed measures will be generated every fourth time this test runs, and also every time the test detects a problem. You can modify this frequency, if you so desire. Also, if you intend to disable the detailed diagnosis capability for this test, you can do so by specifying <i>none</i> against dd frequency. 12. DETAILED DIAGNOSIS - To make diagnosis more efficient and accurate, the eG Enterprise suite embeds an optional detailed diagnostic capability. With this capability, the eG agents can be configured to run detailed, more elaborate tests as and when specific problems are detected. To enable the detailed diagnosis capability of this test for a particular server, choose the On option. To disable the capability, click on the Off option. <p>The option to selectively enable/disable the detailed diagnosis capability will be available only if the following conditions are fulfilled:</p> <ul style="list-style-type: none"> • The eG manager license should allow the detailed diagnosis capability • Both the normal and abnormal frequencies configured for the detailed diagnosis measures should not be 0.
Outputs of the test	One set of results for each disk within each disk supported by the storage device

Measurements made by the test	Measurement	Measurement Unit	Interpretation																																										
	<p>State: Indicates the current state of this disk.</p>	Status	<p>The states this measure reports and the numeric values that correspond to each of the states are as follows:</p> <table border="1" data-bbox="886 418 1426 1516"> <thead> <tr> <th data-bbox="894 418 1139 492">State</th><th data-bbox="1139 418 1426 492">Numeric Value</th></tr> </thead> <tbody> <tr><td data-bbox="894 492 1139 544">Failed</td><td data-bbox="1139 492 1426 544">0</td></tr> <tr><td data-bbox="894 544 1139 597">Off</td><td data-bbox="1139 544 1426 597">1</td></tr> <tr><td data-bbox="894 597 1139 650">Removed</td><td data-bbox="1139 597 1426 650">2</td></tr> <tr><td data-bbox="894 650 1139 703">Binding</td><td data-bbox="1139 650 1426 703">3</td></tr> <tr><td data-bbox="894 703 1139 756">Empty</td><td data-bbox="1139 703 1426 756">4</td></tr> <tr><td data-bbox="894 756 1139 808">Enabled</td><td data-bbox="1139 756 1426 808">5</td></tr> <tr><td data-bbox="894 808 1139 861">Expanding</td><td data-bbox="1139 808 1426 861">6</td></tr> <tr><td data-bbox="894 861 1139 914">Unbound</td><td data-bbox="1139 861 1426 914">7</td></tr> <tr><td data-bbox="894 914 1139 967">Powering up</td><td data-bbox="1139 914 1426 967">8</td></tr> <tr><td data-bbox="894 967 1139 1020">Ready</td><td data-bbox="1139 967 1426 1020">9</td></tr> <tr><td data-bbox="894 1020 1139 1094">Reduced power, Transitioning</td><td data-bbox="1139 1020 1426 1094">10</td></tr> <tr><td data-bbox="894 1094 1139 1146">Hot spare ready</td><td data-bbox="1139 1094 1426 1146">11</td></tr> <tr><td data-bbox="894 1146 1139 1199">Unknown</td><td data-bbox="1139 1146 1426 1199">12</td></tr> <tr><td data-bbox="894 1199 1139 1252">Formatting</td><td data-bbox="1139 1199 1426 1252">13</td></tr> <tr><td data-bbox="894 1252 1139 1305">Equilizing</td><td data-bbox="1139 1252 1426 1305">14</td></tr> <tr><td data-bbox="894 1305 1139 1358">Rebuilding</td><td data-bbox="1139 1305 1426 1358">15</td></tr> <tr><td data-bbox="894 1358 1139 1410">Full power</td><td data-bbox="1139 1358 1426 1410">16</td></tr> <tr><td data-bbox="894 1410 1139 1463">Low power</td><td data-bbox="1139 1410 1426 1463">17</td></tr> <tr><td data-bbox="894 1463 1139 1516">Unformatted</td><td data-bbox="1139 1463 1426 1516">18</td></tr> <tr><td data-bbox="894 1516 1139 1569">Unsupported</td><td data-bbox="1139 1516 1426 1569">19</td></tr> </tbody> </table> <p>Note: By default, this measure reports the States listed in the table above to indicate the state of a disk. The graph of this measure however, represents disk state using the numeric equivalents - <i>0 to 19</i>.</p>	State	Numeric Value	Failed	0	Off	1	Removed	2	Binding	3	Empty	4	Enabled	5	Expanding	6	Unbound	7	Powering up	8	Ready	9	Reduced power, Transitioning	10	Hot spare ready	11	Unknown	12	Formatting	13	Equilizing	14	Rebuilding	15	Full power	16	Low power	17	Unformatted	18	Unsupported	19
State	Numeric Value																																												
Failed	0																																												
Off	1																																												
Removed	2																																												
Binding	3																																												
Empty	4																																												
Enabled	5																																												
Expanding	6																																												
Unbound	7																																												
Powering up	8																																												
Ready	9																																												
Reduced power, Transitioning	10																																												
Hot spare ready	11																																												
Unknown	12																																												
Formatting	13																																												
Equilizing	14																																												
Rebuilding	15																																												
Full power	16																																												
Low power	17																																												
Unformatted	18																																												
Unsupported	19																																												
	<p>LUNs: Indicates the number of LUNs that are sharing this disk.</p>	Number	Use the detailed diagnosis of this measure to know which LUNs are sharing this disk.																																										

	Busy ticks: Indicates the percent utilization of this disk.	Percent	The values in percent and their respective states are listed below: <ul style="list-style-type: none"> ▪ 90%-Critical(Disk Full) ▪ 80%-Major ▪ 60%-Minor
	Hard read errors: Indicates the number of hard read errors in this disk.	Number	The values and their respective states are listed below: <ul style="list-style-type: none"> ▪ 10 - critical ▪ 5 - major ▪ 2 - minor Increase in the value of this measure indicates that the disk life is going to end or fail.
	Hard write errors: Indicates the number of hard write errors in this disk.	Number	The values and their respective states are listed below: <ul style="list-style-type: none"> ▪ 10 - critical ▪ 5 - major ▪ 2 - minor Increase in the value of this measure indicates disk life is going to end or fail.
	Soft read errors: Indicates the number of uncorrected read errors in this disk.	Number	The values and their respective states are listed below: <ul style="list-style-type: none"> ▪ 10 - critical ▪ 5 - major ▪ 2 - minor Increase in value of this measure indicates disk life is going to end or fail.

	Soft write errors: Indicates the number of uncorrected write errors in this disk.	Number	<p>The values and their respective states are listed below:</p> <ul style="list-style-type: none"> • 10 - critical • 5 - major • 2 - minor <p>Increase in value of this measure indicates disk life is going to end or fail.</p>
	Read requests: Indicates the number of read requests made per second to this disk.	Reqs/Sec	Compare the value of these measures across disks to isolate overloaded disks. This will also reveal irregularities in load balancing across disks.
	Write requests: Indicates the number of write requests made per second to this disk.	Reqs/Sec	
	Data reads: Indicates the rate at which data is read from this disk.	MB/Sec	
	Data writes: Indicates the rate at which data is written to this disk.	MB/Sec	
	Total bandwidth: Indicates the sum of data reads and data writes to this disk.	MB/Sec	
	Total capacity: Indicates the total size of this disk.	GB	
	User capacity: Indicates the amount of space on this disk that is assigned to bound LUNs.	GB	

	Usage: Indicates the percentage of space in this disk that is currently in use.	Percent	Ideally, the value of this measure should be low. A consistent increase in this value could indicate a gradual, but steady erosion of space in the disk.
	Read retries: Indicates the number of times read requests to this disk were retried.	Number	A low value is desired for this measure.
	Write retries: Indicates the number of times write requests to this disk were retried.	Number	A low value is desired for this measure.
	Remapped sectors: Indicates the number of sectors on this disk that were remapped to new locations on the disk due to read/write errors.	Number	A low value is desired for this measure.
	Request service time: Indicates the time taken by this disk to service requests.	Secs	A high value is typically indicative of a request processing bottleneck in the disk. Compare the value of this measure across disks to know which disks are experiencing significant latencies.

The detailed diagnosis of the *LUNs* measure, if enabled, reveals the IDs of the LUNs that are sharing a particular disk, and the Raid type of each LUN.

Disk details		
Time	LUN Name	Raid Type
Mar 18, 2011 14:24:07		
	Virtual Disk 1	RAIDS
	Virtual Disk 2	RAIDS
	Virtual Disk 3	RAIDS
	Virtual Disk 4	RAIDS
	Virtual Disk 5	RAIDS
	Virtual Disk 6	RAIDS

Figure 1.14: The detailed diagnosis of the LUNs measure

1.4.2 EMC RAID Disks Test

This test monitors the current state, overall health, and the load-balancing capability of each disk in the EMC storage system. With the help of this test, administrators can not only identify failed disks, but can also predict the potential failure of a disk, so that efforts can be undertaken to avert the same. In addition, the test also points administrators to disks that are handling more I/O requests than the rest, thus shedding light on irregularities in the distribution of

I/O load across disks and prompting administrators to fine-tune the load-balancing algorithm. In addition, the test also proactively alerts administrators to probable slowdowns in I/O processing by specific disks, thereby enabling administrators to initiate pre-emptive actions.

This test is disabled by default. To enable the test, first select the **Enable/Disable** option from the **Tests** menu of the **Agents** tile. Then, select *EMC Clariion SAN* as the **Component type**, pick this test from the **DISABLED TESTS** list, click the **<** button to enable it, and click the **Update** button.

Purpose	Monitors the current state, overall health, and the load-balancing capability of each disk in the storage system		
Target of the test	An EMC CLARiiON system		
Agent deploying the test	A remote agent		
Configurable parameters for the test	<ol style="list-style-type: none"> TEST PERIOD – How often should the test be executed HOST – The IP address of the storage device PORT - The port number at which the storage device listens. The default is NULL. USER and PASSWORD – The SMI-S Provider is paired with the EMC CIM Object Manager Server to provide an SMI-compliant interface for CLARiiON arrays. Against the USER and PASSWORD parameters, specify the credentials of a user who has been assigned Monitor access to the EMC CIM Object Manager Server paired with EMC CLARiiON's SMI-S provider. CONFIRM PASSWORD – Confirm the PASSWORD by retyping it here. SSL – Set this flag to Yes, if the storage device being monitored is SSL-enabled. ISEMBEDDED – By default, this flag is set to False for an EMC CLARiiON device. Do not disturb this default setting. SERIALNUMBER – If the SMI-S provider has been implemented as a proxy, then such a provider can be configured to manage multiple storage devices. This is why, you will have to explicitly specify which storage system you want the eG agent to monitor. Since each storage system is uniquely identified by a SERIALNUMBER, specify the same here. The serial number for an EMC CLARiiON device will be of the format, FCNMM094900059. NAMESPACE - Specify the namespace that uniquely identifies the profiles specific to the provider in use. For EMC CLARiiON, this parameter will be set to <i>root/emc</i> by default. 		
Outputs of the test	One set of results for each disk on the storage system		
Measurements made by the	Measurement	Measurement Unit	Interpretation

test	<p>Health state: Indicates how healthy this disk currently is.</p>		<p>The values that this measure can report and their corresponding numeric values are discussed in the table below:</p> <table border="1" data-bbox="975 340 1372 853"> <thead> <tr> <th data-bbox="975 340 1122 418">Numeric Value</th><th data-bbox="1122 340 1372 418">Measure Value</th></tr> </thead> <tbody> <tr> <td data-bbox="975 418 1122 487">0</td><td data-bbox="1122 418 1372 487">OK</td></tr> <tr> <td data-bbox="975 487 1122 557">1</td><td data-bbox="1122 487 1372 557">Unknown</td></tr> <tr> <td data-bbox="975 557 1122 627">2</td><td data-bbox="1122 557 1372 627">Degraded/Warning</td></tr> <tr> <td data-bbox="975 627 1122 696">3</td><td data-bbox="1122 627 1372 696">Minor failure</td></tr> <tr> <td data-bbox="975 696 1122 766">4</td><td data-bbox="1122 696 1372 766">Major failure</td></tr> <tr> <td data-bbox="975 766 1122 836">5</td><td data-bbox="1122 766 1372 836">Critical failure</td></tr> <tr> <td data-bbox="975 836 1122 853">6</td><td data-bbox="1122 836 1372 853">Non-recoverable error</td></tr> </tbody> </table> <p> Note By default, this measure reports the Measure Values discussed above to indicate the state of a disk. In the graph of this measure however, states are represented using the numeric equivalents only.</p>	Numeric Value	Measure Value	0	OK	1	Unknown	2	Degraded/Warning	3	Minor failure	4	Major failure	5	Critical failure	6	Non-recoverable error
Numeric Value	Measure Value																		
0	OK																		
1	Unknown																		
2	Degraded/Warning																		
3	Minor failure																		
4	Major failure																		
5	Critical failure																		
6	Non-recoverable error																		

	<p>Operational status: Indicates the current operational state of this disk.</p>		<p>The values that this measure can report and their corresponding numeric values are discussed in the table below:</p> <table border="1"> <thead> <tr> <th>Numeric Value</th><th>Measure Value</th></tr> </thead> <tbody> <tr><td>0</td><td>OK</td></tr> <tr><td>1</td><td>In Service</td></tr> <tr><td>2</td><td>Power Mode</td></tr> <tr><td>3</td><td>Completed</td></tr> <tr><td>4</td><td>Starting</td></tr> <tr><td>5</td><td>Dormant</td></tr> <tr><td>6</td><td>Other</td></tr> <tr><td>7</td><td>Unknown</td></tr> <tr><td>8</td><td>Stopping</td></tr> <tr><td>9</td><td>Stressed</td></tr> <tr><td>10</td><td>Stopped</td></tr> <tr><td>11</td><td>Supporting Entity in Error</td></tr> <tr><td>12</td><td>Degraded or Predicted Failure</td></tr> <tr><td>13</td><td>Predictive Failure</td></tr> <tr><td>14</td><td>Lost Communication</td></tr> <tr><td>15</td><td>No Contact</td></tr> <tr><td>16</td><td>Aborted</td></tr> <tr><td>17</td><td>Error</td></tr> <tr><td>18</td><td>Non-Recoverable Error</td></tr> </tbody> </table>	Numeric Value	Measure Value	0	OK	1	In Service	2	Power Mode	3	Completed	4	Starting	5	Dormant	6	Other	7	Unknown	8	Stopping	9	Stressed	10	Stopped	11	Supporting Entity in Error	12	Degraded or Predicted Failure	13	Predictive Failure	14	Lost Communication	15	No Contact	16	Aborted	17	Error	18	Non-Recoverable Error
Numeric Value	Measure Value																																										
0	OK																																										
1	In Service																																										
2	Power Mode																																										
3	Completed																																										
4	Starting																																										
5	Dormant																																										
6	Other																																										
7	Unknown																																										
8	Stopping																																										
9	Stressed																																										
10	Stopped																																										
11	Supporting Entity in Error																																										
12	Degraded or Predicted Failure																																										
13	Predictive Failure																																										
14	Lost Communication																																										
15	No Contact																																										
16	Aborted																																										
17	Error																																										
18	Non-Recoverable Error																																										

			 Note	By default, this measure reports the Measure Values discussed above to indicate the operational state of a disk. In the graph of this measure however, operational states are represented using the numeric equivalents only.
--	--	--	---	--

	<p>Detailed operational state: Describes the current operational state of this disk.</p>		<p>This measure will be reported only if the API provides a detailed operational state.</p> <p>Typically, the detailed state will describe why the disk is in a particular operational state. For instance, if the <i>Operational status</i> measure reports the value <i>Stopping</i> for a disk, then this measure will explain why that disk is being stopped.</p> <p>The values that this measure can report and their corresponding numeric values are discussed in the table below:</p> <table border="1" data-bbox="975 629 1372 1320"> <thead> <tr> <th data-bbox="975 629 1122 713">Numeric Value</th><th data-bbox="1122 629 1372 713">Measure Value</th></tr> </thead> <tbody> <tr> <td data-bbox="975 713 1122 783">0</td><td data-bbox="1122 713 1372 783">Online</td></tr> <tr> <td data-bbox="975 783 1122 853">1</td><td data-bbox="1122 783 1372 853">Success</td></tr> <tr> <td data-bbox="975 853 1122 922">2</td><td data-bbox="1122 853 1372 922">Power Saving Mode</td></tr> <tr> <td data-bbox="975 922 1122 971">3</td><td data-bbox="1122 922 1372 971">Write Protected</td></tr> <tr> <td data-bbox="975 971 1122 1041">4</td><td data-bbox="1122 971 1372 1041">Write Disabled</td></tr> <tr> <td data-bbox="975 1041 1122 1110">5</td><td data-bbox="1122 1041 1372 1110">Not Ready</td></tr> <tr> <td data-bbox="975 1110 1122 1180">6</td><td data-bbox="1122 1110 1372 1180">Removed</td></tr> <tr> <td data-bbox="975 1180 1122 1250">7</td><td data-bbox="1122 1180 1372 1250">Rebooting</td></tr> <tr> <td data-bbox="975 1250 1122 1320">8</td><td data-bbox="1122 1250 1372 1320">Offline</td></tr> <tr> <td data-bbox="975 1320 1122 1320">9</td><td data-bbox="1122 1320 1372 1320">Failure</td></tr> </tbody> </table> <p> By default, this measure reports the Measure Values discussed above to indicate the detailed operational state of a disk. In the graph of this measure however, detailed operational states are represented using the numeric equivalents only.</p>	Numeric Value	Measure Value	0	Online	1	Success	2	Power Saving Mode	3	Write Protected	4	Write Disabled	5	Not Ready	6	Removed	7	Rebooting	8	Offline	9	Failure
Numeric Value	Measure Value																								
0	Online																								
1	Success																								
2	Power Saving Mode																								
3	Write Protected																								
4	Write Disabled																								
5	Not Ready																								
6	Removed																								
7	Rebooting																								
8	Offline																								
9	Failure																								
	<p>Data transmitted: Indicates the rate at which data was transmitted by this disk.</p>	MB/Sec																							

	IOPS: Indicates the rate at which I/O operations were performed on this disk.	IOPS	Compare the value of this measure across disks to know which disk handled the maximum number of I/O requests and which handled the least. If the gap between the two is very high, then it indicates serious irregularities in load-balancing across disks. You may then want to take a look at the <i>Reads</i> and <i>Writes</i> measure to understand what to fine-tune – the load-balancing algorithm for read requests or that of the write requests.
	Reads: Indicates the rate at which read operations were performed on this disk.	Reads/Sec	Compare the value of this measure across disks to know which disk handled the maximum number of read requests and which handled the least. If the gap between the two is very high, then it indicates serious irregularities in load-balancing across disks.
	Writes: Indicates the rate at which write operations were performed on this disk.	Writes/Sec	Compare the value of this measure across disks to know which disk handled the maximum number of write requests and which handled the least. If the gap between the two is very high, then it indicates serious irregularities in load-balancing across disks.
	Data reads: Indicates the rate at which data is read from this disk.	MB/Sec	Compare the value of these measures across disks to identify the slowest disk in terms of servicing read and write requests (respectively).
	Data written: Indicates the rate at which data is written to this disk.	MB/Sec	
	Disk busy: Indicates the percentage of time this disk was busy processing requests.	Percent	Compare the value of this measure across disks to know which disk was the busiest and which disk was not. If the gap between the two is very high, then it indicates serious irregularities in load-balancing across disks.
	Average read size: Indicates the amount of data read from this disk per I/O operation	MB/Op	Compare the value of these measures across disks to identify the slowest disk in terms of servicing read and write requests (respectively).
	Average write size: Indicates the amount of data written to this disk per I/O operation.	MB/Op	

	Read hit: Indicates the percentage of read requests that were serviced by the cache of this disk.	Percent	A high value is desired for this measure. A very low value is a cause for concern, as it indicates that cache usage is very poor; this in turn implies that direct disk accesses, which are expensive operations, are high.
	Write hit: Indicates the percentage of write requests that were serviced by the cache of this disk.	Percent	A high value is desired for this measure. A very low value is a cause for concern, as it indicates that cache usage is very poor; this in turn implies that direct disk accesses, which are expensive operations, are high.
	Average response time: Indicates the time taken by this disk to respond to I/O requests.	Microsecs	Ideally, this value should be low. If not, it implies that the disk is slow.
	EMC queue length: Indicates the number of requests that are in queue for this disk.	Number	A consistent increase in this value indicates a potential processing bottleneck with the disk.
	EMC queue arrivals: Indicates the number of times a user request arrived while at least one other request was being processed.	Number	

1.5 The EMC Disk Pools Layer

RAID, an acronym for *Redundant Array of Independent Disks* (Changed from its original term Redundant Array of Inexpensive Disks), is a technology that provides increased storage functions and reliability through redundancy. This is achieved by combining multiple disk drive components into a logical unit, where data is distributed across the drives in one of several ways called "RAID levels".

RAID Groups also allow you to configure the Clariion in a way so that you will know what LUNs, applications, etc., live on what set of disks in the back of the Clariion. For instance, you would not want an Oracle Database LUN on the same RAID Group (Disks) as a SQL Database running on the same Clariion. This allows you to create a RAID Group of a set of disks for the Oracle Database, and another RAID Group of a different set of disks for the SQL Database.

Using the test mapped to this layer, you can monitor the current state, capacity, and usage of each RAID group on the Clariion storage system.




Figure 1.15: The tests mapped to the EMC Disk Pools layer

1.5.1 Clariion RAID Groups Test

Sufficient disk space should be available in a RAID group, as new LUNs cannot be created in a RAID group that suffers from a severe space contention. Also, with many critical applications attached to RAID groups, it is essential for administrators to track the capacity and usage of each RAID group on the storage system to figure out whether enough disk space is available in all RAIDs to support the storage requirements of these applications.

This test auto-discovers the RAID groups on the storage system, and reports the current state, capacity, space usage, and space availability of each RAID group so that, you can instantly identify the RAID groups that are running out of space.

Purpose	Auto-discovers the RAID groups on the storage system, and reports the current state, capacity, space usage, and space availability of each RAID group so that, you can instantly identify the RAID groups that are running out of space
Target of the test	An EMC CLARiON storage device
Agent deploying the test	A remote agent

Configurable parameters for the test	<ol style="list-style-type: none"> 1. TESTPERIOD – How often should the test be executed 2. HOST – The IP address of the storage device 3. PORT - The port number at which the storage device listens. The default is NULL. 4. CLARIION IP - By default, the host IP will be displayed here. If the eG agent has also been configured to use the SMI-S provider for metrics collection, then the IP address of host on which the SMI-S provider has been installed, will be displayed here by default. In this case, you should change the value of this parameter to reflect the IP address of the EMC CLARIION storage device. However, if the eG agent uses only the NaviSphere CLI for monitoring, then the default settings can remain. 5. NAVISECCLIPATH - The eG agent uses the command-line utility, NaviSecCli.exe, which is part of the NaviSphere Management Suite, to communicate with and monitor the storage device. To enable the eG agent to invoke the CLI, configure the full path to the CLI in the NAVISECCLIPATH text box. 6. USER NAME and PASSWORD - Provide the credentials of a user who is authorized to access the storage device in the user name and password text boxes. 7. CONFIRM PASSWORD - Confirm the password by retyping it here. 8. IGNORE INVALID RAID GROUPS - By default, this flag is set to No, indicating that the test monitors all RAID groups by default. Set this flag to Yes if you want the test to consider only the 'valid' RAID groups for monitoring. 9. EXCLUDE RAID GROUPS - Provide a comma-separated list of RAID Group IDs that you want to exclude from the monitoring scope of this test. By default, this is set to <i>none</i> indicating that no RAID groups are excluded by default. 10. DD FREQUENCY - - Refers to the frequency with which detailed diagnosis measures are to be generated for this test. The default is <i>4:1</i>. This indicates that, by default, detailed measures will be generated every fourth time this test runs, and also every time the test detects a problem. You can modify this frequency, if you so desire. Also, if you intend to disable the detailed diagnosis capability for this test, you can do so by specifying <i>none</i> against dd frequency. 11. DETAILED DIAGNOSIS - To make diagnosis more efficient and accurate, the eG Enterprise suite embeds an optional detailed diagnostic capability. With this capability, the eG agents can be configured to run detailed, more elaborate tests as and when specific problems are detected. To enable the detailed diagnosis capability of this test for a particular server, choose the On option. To disable the capability, click on the Off option. The option to selectively enable/disable the detailed diagnosis capability will be available only if the following conditions are fulfilled: <ul style="list-style-type: none"> • The eG manager license should allow the detailed diagnosis capability • Both the normal and abnormal frequencies configured for the detailed diagnosis measures should not be 0. 12. TIMEOUT - Indicate the duration (in seconds) for which this test should wait for a response from the storage device. By default, this is set to 600 seconds. Note that the 'TIMEOUT' value should always be set between 3 and 600 seconds only.
Outputs of the test	One set of results for each RAID group supported by the storage device

Measurements made by the test	Measurement	Measurement Unit	Interpretation																		
	<p>Raid group state: Indicates the current state of this RAID group.</p>		<p>This measure reports any of the following values as the state of the RAID group:</p> <ul style="list-style-type: none"> • Invalid • Valid • Defragmenting • Valid LUNs • Expanding • Busy • Explicit Remove <p>The numeric values that correspond to each of the states discussed above are as follows:</p> <table border="1" data-bbox="886 910 1424 1353"> <thead> <tr> <th data-bbox="886 910 1139 952">Numeric Value</th><th data-bbox="1139 910 1424 952">State</th></tr> </thead> <tbody> <tr> <td data-bbox="1008 963 1024 984">0</td><td data-bbox="1261 963 1334 984">Invalid</td></tr> <tr> <td data-bbox="1008 1005 1024 1026">1</td><td data-bbox="1261 1005 1334 1026">Valid</td></tr> <tr> <td data-bbox="1008 1047 1024 1068">2</td><td data-bbox="1212 1047 1375 1068">Defragmenting</td></tr> <tr> <td data-bbox="1008 1089 1024 1110">3</td><td data-bbox="1228 1089 1359 1110">Valid LUNs</td></tr> <tr> <td data-bbox="1008 1132 1024 1153">4</td><td data-bbox="1228 1132 1359 1153">Expanding</td></tr> <tr> <td data-bbox="1008 1174 1024 1195">5</td><td data-bbox="1261 1174 1334 1195">Busy</td></tr> <tr> <td data-bbox="1008 1216 1024 1237">6</td><td data-bbox="1212 1216 1375 1237">Explicit Remove</td></tr> <tr> <td data-bbox="1008 1258 1024 1279">7</td><td data-bbox="1261 1258 1334 1279">Other</td></tr> </tbody> </table> <p>Note:</p> <p>By default, this measure reports the States listed in the table above to indicate the state of a RAID group. The graph of this measure however, represents RAID group state using the numeric equivalents - <i>0 to 7</i>.</p>	Numeric Value	State	0	Invalid	1	Valid	2	Defragmenting	3	Valid LUNs	4	Expanding	5	Busy	6	Explicit Remove	7	Other
Numeric Value	State																				
0	Invalid																				
1	Valid																				
2	Defragmenting																				
3	Valid LUNs																				
4	Expanding																				
5	Busy																				
6	Explicit Remove																				
7	Other																				
	<p>Disk count: Indicates the number of disks assigned to this RAID group.</p>	Number	To know which disks have been assigned to a RAID group, use the detailed diagnosis of this measure.																		

	Lun count: Indicates the number of LUNs sharing this RAID group.	Number	To know which LUNs are sharing a particular RAID group, use the detailed diagnosis of this measure.
	Raw capacity: Indicates the amount of raw capacity (in millions of blocks) of this RAID group that is available for binding LUNs.	TB	
	Logical capacity: Indicates the logical capacity of this RAID group.	MB	
	Free capacity: Indicates the amount of unused capacity in this RAID group.	GB	A high value is generally desired for this measure. A very low value or a consistent dip in this value could indicate a space crunch in the RAID group, which in turn can prevent the creation of new LUNs in the group.
	Free: Indicates the percentage of free space in this RAID group.	Percent	A high value is generally desired for this measure. A very low value or a consistent dip in this value could indicate a space crunch in the RAID group, which in turn can prevent the creation of new LUNs in the group.
	Defragmented: Indicates the progress (in percentage) of the defragmentation process on this RAID group.	Percent	As you unbind and rebind LUNs on a RAID Group, gaps may be created in the contiguous space across the Group's disks, fragmenting the RAID Group. Fragmentation makes less space available for creating new LUNs. Defragment a RAID Group to compress these gaps and provide more contiguous free space across the disks. Using this measure, you can easily track the progress of the defragmentation activity on each RAID group, and can receive a fair idea as to how long it would take for the defragmentation to complete.
	Expanded: Indicates the progress (in percentage) of a RAID group expansion performed on this RAID group.	Percent	You can expand an existing RAID group by adding more disks to it. Expansion makes have more space available in the raid group to create new LUNs. Using this measure, you can easily track the progress of the expansion of each RAID group, and can receive a fair idea as to how long it would take for the expansion to complete.

	Maximum number of disks: Indicates the maximum number of disks that this RAID group can contain.	Number									
	Maximum number of LUNs: Indicates the maximum number of LUNs that can be created in this RAID group.	Number									
	Free contiguous group of unbound segments: Indicates the size of the largest contiguous span of free space in this RAID group.	GB	<p>The larger this space, higher will be the number of LUNs that can be created on the corresponding RAID group.</p>								
	Defrag/Expand priority: Indicates the current expansion / defragmentation priority of this RAID group.		<p>This measure can report one of the following values:</p> <ul style="list-style-type: none"> • High • Medium • Low <p>The higher the priority, the more system resources that are used, which can reduce system performance.</p> <p>The numeric values that correspond to each of the priorities discussed above are as follows:</p> <table border="1"> <thead> <tr> <th>Numeric Value</th> <th>Priority</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>Low</td> </tr> <tr> <td>1</td> <td>Medium</td> </tr> <tr> <td>2</td> <td>High</td> </tr> </tbody> </table> <p>Note:</p> <p>By default, this measure reports the Priorities listed in the table above to indicate the defrag/expansion priority of a RAID group. The graph of this measure however, represents priorities using the numeric equivalents - 0 to 2.</p>	Numeric Value	Priority	0	Low	1	Medium	2	High
Numeric Value	Priority										
0	Low										
1	Medium										
2	High										

	<p>Disk expanding: Indicates whether any disk in this RAID group is currently expanding or not.</p>	<p>If no disks in the RAID group are expanding currently, then this measure will report the value <i>N/A</i>. If one or more disks are currently expanding, then this measure will report the value <i>Available</i>.</p> <p>The numeric values that correspond to each of the expansion states discussed above are as follows:</p> <table border="1" data-bbox="887 593 1421 741"> <thead> <tr> <th data-bbox="887 593 1139 635">Numeric Value</th><th data-bbox="1139 593 1421 635">State</th></tr> </thead> <tbody> <tr> <td data-bbox="887 635 1139 677">0</td><td data-bbox="1139 635 1421 677">N/A</td></tr> <tr> <td data-bbox="887 677 1139 741">1</td><td data-bbox="1139 677 1421 741">Available</td></tr> </tbody> </table> <p>Note: By default, this measure reports the States listed in the table above to indicate the expansion state of a RAID group. The graph of this measure however, represents expansion states using the numeric equivalents - <i>0</i> and <i>1</i>.</p>	Numeric Value	State	0	N/A	1	Available
Numeric Value	State							
0	N/A							
1	Available							
	<p>Lun expansion: Indicates whether LUN expansion is enabled or disabled for this RAID group.</p>	<p>If LUN expansion is enabled for a RAID group, then this measure will report the value <i>Enabled</i>. If not, then the value would be <i>Disabled</i>.</p> <p>The numeric values that correspond to each of the expansion states discussed above are as follows:</p> <table border="1" data-bbox="887 1368 1421 1516"> <thead> <tr> <th data-bbox="887 1368 1139 1410">Numeric Value</th><th data-bbox="1139 1368 1421 1410">State</th></tr> </thead> <tbody> <tr> <td data-bbox="887 1410 1139 1453">0</td><td data-bbox="1139 1410 1421 1453">Disabled</td></tr> <tr> <td data-bbox="887 1453 1139 1516">1</td><td data-bbox="1139 1453 1421 1516">Enabled</td></tr> </tbody> </table> <p>Note: By default, this measure reports the States listed in the table above to indicate the LUN expansion state of a RAID group. The graph of this measure however, represents expansion states using the numeric equivalents - <i>0</i> and <i>1</i>.</p>	Numeric Value	State	0	Disabled	1	Enabled
Numeric Value	State							
0	Disabled							
1	Enabled							

The detailed diagnosis of the *Disk count* measure lists the disks that have been assigned to a particular RAID group.

Disk details	
Time	Disk List
Mar 18, 2011 14:25:21	Enclosure 0 Disk 3
	Enclosure 0 Disk 2
	Enclosure 0 Disk 1
	Enclosure 0 Disk 0

Figure 1.16: The detailed diagnosis of the Disk count measure

The detailed diagnosis of the *LUN count* measure lists the LUNs that are sharing a particular RAID group.

LUN details	
Time	LUN List
Mar 18, 2011 14:25:21	Virtual Disk 1
	Virtual Disk 2
	Virtual Disk 3
	Virtual Disk 4
	Virtual Disk 5
	Virtual Disk 6

Figure 1.17: The detailed diagnosis of the LUN count measure

1.6 The EMC Luns Layer

A LUN is a Logical Unit Number. It can be used to refer to an entire physical disk, or a subset of a larger physical disk or disk volume. The physical disk or disk volume could be an entire single disk drive, a partition (subset) of a single disk drive, or disk volume from a RAID controller comprising of multiple disk drives aggregated together for larger capacity and redundancy.

Isolate bound and unbound LUNs, overloaded LUNS and those that are experiencing errors using the test mapped to this layer.

Tests	
<input checked="" type="checkbox"/> EMC Luns	Search <input type="text"/> <input type="button"/>
<input checked="" type="checkbox"/> Clarion LUNs	<input checked="" type="checkbox"/> All
<input checked="" type="checkbox"/> Hot Spare <input checked="" type="checkbox"/> Virtual Disk 1 <input checked="" type="checkbox"/> Virtual Disk 10 <input checked="" type="checkbox"/> Virtual Disk 11 <input checked="" type="checkbox"/> Virtual Disk 12 <input checked="" type="checkbox"/> Virtual Disk 13 <input checked="" type="checkbox"/> Virtual Disk 14 <input checked="" type="checkbox"/> Virtual Disk 2	

Figure 1.18: The test mapped to the EMC Luns layer

1.6.1 Clariion LUNs Test

This test reports the current state of each LUN on a storage system, and measures the level of I/O activity on the

LUNs.

Purpose	Reports the current state of each LUN on a storage system, and measures the level of I/O activity on the LUNs
Target of the test	An EMC CLARiiON storage device
Agent deploying the test	A remote agent

Configurable parameters for the test	<ol style="list-style-type: none"> 1. TESTPERIOD – How often should the test be executed 2. HOST – The IP address of the storage device 3. PORT - The port number at which the storage device listens. The default is NULL. 4. CLARIION IP - By default, the host IP will be displayed here. If the eG agent has also been configured to use the SMI-S provider for metrics collection, then the IP address of host on which the SMI-S provider has been installed, will be displayed here by default. In this case, you should change the value of this parameter to reflect the IP address of the EMC CLARIION storage device. However, if the eG agent uses only the NaviSphere CLI for monitoring, then the default settings can remain. 5. NAVISECCLIPATH - The eG agent uses the command-line utility, NaviSecCli.exe, which is part of the NaviSphere Management Suite, to communicate with and monitor the storage device. To enable the eG agent to invoke the CLI, configure the full path to the CLI in the NAVISECCLIPATH text box. 6. USER NAME and PASSWORD - Provide the credentials of a user who is authorized to access the storage device in the user name and password text boxes. 7. CONFIRM PASSWORD - Confirm the password by retyping it here. 8. IGNORE DISABLED LUNS - By default, this flag is set to No, indicating that the test monitors all LUNs by default. Set this flag to Yes if you want the test to consider only the 'enabled' LUNs for monitoring. 9. EXCLUDE LUNS - Provide a comma-separated list of LUNs that you want to exclude from the monitoring scope of this test. By default, this is set to <i>none</i> indicating that no LUNs are excluded by default. 10. DD FREQUENCY - - Refers to the frequency with which detailed diagnosis measures are to be generated for this test. The default is <i>4:1</i>. This indicates that, by default, detailed measures will be generated every fourth time this test runs, and also every time the test detects a problem. You can modify this frequency, if you so desire. Also, if you intend to disable the detailed diagnosis capability for this test, you can do so by specifying <i>none</i> against dd frequency. 11. DETAILED DIAGNOSIS - To make diagnosis more efficient and accurate, the eG Enterprise suite embeds an optional detailed diagnostic capability. With this capability, the eG agents can be configured to run detailed, more elaborate tests as and when specific problems are detected. To enable the detailed diagnosis capability of this test for a particular server, choose the On option. To disable the capability, click on the Off option. The option to selectively enable/disable the detailed diagnosis capability will be available only if the following conditions are fulfilled: <ul style="list-style-type: none"> • The eG manager license should allow the detailed diagnosis capability • Both the normal and abnormal frequencies configured for the detailed diagnosis measures should not be 0. 12. TIMEOUT - Indicate the duration (in seconds) for which this test should wait for a response from the storage device. By default, this is set to 600 seconds. Note that the 'TIMEOUT' value should always be set between 3 and 600 seconds only.
Outputs of the test	One set of results for each LUN that is monitored on the storage system

Measurements made by the test	Measurement	Measurement Unit	Interpretation						
	<p>LUN binding completion: Indicates the current state of this LUN.</p>	Status	<p>If the state reported by this measure is <i>Bound</i>, it indicates that the LUN is currently in a <i>bound state</i>. A bind creates LUNs on a RAID GROUP. Binding a LUN involves the preparation of allocated storage space. This preparation is particularly important when storage capacity is being reallocated for reuse.</p> <p>LUNs are bound after RAID GROUPS are created. LUNs are available for use immediately after they are created, but the bind is not strictly complete until after all the bound storage has been prepared and verified.</p> <p>During the preparation step, the storage allocated to the LUN is overwritten with binary zeroes. These zeroes erase any previous data from the storage and set up for the parity calculation. When zeroing is complete, parity and metadata is calculated for the LUN sectors.</p> <p>If the state reported by this measure is <i>Unbound</i>, it indicates that the LUN is currently in an unbound state.</p> <p>The numeric values that correspond to each of the states discussed above are as follows:</p> <table border="1" data-bbox="886 1121 1421 1269"> <thead> <tr> <th data-bbox="886 1121 1139 1163">Value</th><th data-bbox="1139 1121 1421 1163">State</th></tr> </thead> <tbody> <tr> <td data-bbox="886 1163 1139 1205">1</td><td data-bbox="1139 1163 1421 1205">Bound</td></tr> <tr> <td data-bbox="886 1205 1139 1248">0</td><td data-bbox="1139 1205 1421 1248">Not bound</td></tr> </tbody> </table> <p>Note:</p> <p>By default, this measure reports the values <i>Bound</i> or <i>Unbound</i> to indicate the state of a LUN. The graph of this measure however, represents the LUN state using the numeric equivalents - <i>0</i> or <i>1</i>.</p> <p>Use the detailed diagnosis of this measure to view additional details of a LUN.</p>	Value	State	1	Bound	0	Not bound
Value	State								
1	Bound								
0	Not bound								
	<p>Total hard errors: Indicates the number of hard errors on this LUN.</p>	Number	<p>The values and their respective states are listed below:</p> <ul style="list-style-type: none"> ▪ 10 - critical ▪ 5 - major ▪ 2 - minor <p>Increase in the value of this measure indicates that the LUN life is going to end or fail.</p>						

	Total soft errors: Indicates the total number of uncorrected read and write errors on this LUN.	Number	The values and their respective states are listed below: <ul style="list-style-type: none">▪ 10 - critical▪ 5 - major▪ 2 - minor Increase in value of this measure indicates disk life is going to end or fail.
	Average queue requests: Indicates the average number of requests to this LUN that are in queue.	Number	A very high value could indicate a processing bottleneck on this LUN.
	Current read cache hits: Indicates the number of times read requests to this LUN were fulfilled by the read cache.	Number	A high value is desired for this measure.
	Current write cache hits: Indicates the number of times write requests to this LUN were fulfilled by the write cache.	Number	A high value is desired for this measure.
	Read cache misses: Indicates the number of times read requests to this LUN were not serviced by the read cache.	Number	Ideally, the value of this measure should be low.
	Read hit ratio: Indicates the percentage of read requests to this LUN that were serviced by the cache	Percent	Ideally, the value of this measure should be high. A low value indicates that many read requests are serviced by direct disk accesses, which is a more expensive operation in terms of processing overheads.
	Write hit ratio: Indicates the percentage of write requests to this LUN that were serviced by the cache.	Percent	Ideally, the value of this measure should be high. A low value indicates that data is often directly written to the disk, which is a more expensive operation in terms of processing overheads.

	Read requests: Indicates the number of read requests made per second to this LUN.	Reqs/Sec	Comparing the value of these measures across LUNs will clearly indicate which LUN is the busiest in terms of the number of read and write requests handled – it could also shed light on irregularities in load balancing across the LUNs.
	Write requests: Indicates the number of write requests made per second to this LUN.	Reqs/Sec	
	Data reads: Indicates the rate at which data was read from this LUN.	Blocks/Sec	Comparing the value of these measures across LUNs will clearly indicate which LUN is the busiest in terms of the rate at which data is read and written – it could also shed light on irregularities in load balancing across the LUNs.
	Data writes: Indicate the rate at which data was written to this LUN.	Blocks/Sec	
	Total I/O: Indicates the rate of the I/O activity on this LUN.	Number	
	Rebuild process completion: Indicates the percentage of this LUN that has been rebuilt.	Percent	A rebuild replaces a failed hard disk within a RAID group with an operational disk. If one or more LUNs are bound to the RAID group with the failed disk, then, all the LUNs affected by the failure are rebuilt. A rebuild restores a LUN to its fully assigned number of hard drives using an available hot spare should a drive in one of the RAID groups fail. LUNs are rebuilt one by one. Each LUN is rebuilt by its owning Storage Processor (SP).

	LUN binding completion: Indicates the percentage of the LUN binding process that is complete.	Percent	<p>A bind is an information organization, data security, and data integrity feature of CLARiiON. Binding a LUN involves the preparation of allocated storage space. This preparation is particularly important when storage capacity is being reallocated for reuse. This reuse of storage includes erasing any previous data found on the hard drives, and the setting of parity and metadata for the storage.</p> <p>LUNs are typically available for use immediately after they are bound. However, the bind is not strictly complete until after all the bound storage has been prepared and verified. Depending on the LUN size and verify priority, these two steps may take several hours. Using the value of this measure, you will be able to track the progress of the binding function, and will be able to gauge how much longer it will take for the binding to complete.</p>
	LUN capacity: Indicates the total capacity of this LUN.	GB	
	LUN size: Indicates the LUN size in blocks.	Blocks	

The detailed diagnosis of the *State* measure reveals whether the target LUN is a private LUN or not, the Raid group to which the LUN belongs, the Raid type, and the storage group name.

LUN details				
Time	isPrivate	RaidType	RaidGroupID	Storage Group
Mar 18, 2011 14:26:13	NO	RAID5	0	esx4-150

Figure 1.19: The detailed diagnosis of the State measure

1.6.2 EMC RAID LUNs Test

A logical unit number (LUN) is a unique identifier used to designate individual or collections of hard disk devices for address by a protocol associated with a SCSI, iSCSI, Fibre Channel (FC) or similar interface. LUNs are central to the management of storage arrays shared over a storage area network (SAN). LUN errors, poor LUN cache usage, and abnormal I/O activity on the LUNs, if not promptly detected and resolved, can hence significantly degrade the performance of the storage array. This is why, it is important that LUN performance is continuously monitored. This can be achieved using the **EMC RAID LUNs** test. This test auto-discovers the LUNs in the storage system and reports the current state of each LUN, captures LUN errors, and measures the level of I/O activity on every LUN, so that administrators are notified of LUN-related problems well before they impact storage system performance.

This test is disabled by default. To enable the test, first select the **Enable/Disable** option from the **Tests** menu of the **Agents** tile. Then, select *EMC Clariion SAN* as the **Component type**, pick this test from the **DISABLED TESTS** list, click the < button to enable it, and click the **Update** button.

Purpose	Auto-discovers the LUNs in the storage system and reports the current state of each LUN, captures LUN errors, and measures the level of I/O activity on every LUN, so that administrators are notified of LUN-related problems well before they impact storage system performance			
Target of the test	An EMC CLARiiON storage system			
Agent deploying the test	A remote agent			
Configurable parameters for the test	<ol style="list-style-type: none"> TEST PERIOD – How often should the test be executed HOST – The IP address of the storage device PORT - The port number at which the storage device listens. The default is NULL. USER and PASSWORD – The SMI-S Provider is paired with the EMC CIM Object Manager Server to provide an SMI-compliant interface for CLARiiON arrays. Against the USER and PASSWORD parameters, specify the credentials of a user who has been assigned Monitor access to the EMC CIM Object Manager Server paired with EMC CLARiiON's SMI-S provider. CONFIRM PASSWORD – Confirm the PASSWORD by retyping it here. SSL – Set this flag to Yes, if the storage device being monitored is SSL-enabled. ISEMBEDDED – By default, this flag is set to False for an EMC CLARiiON device. Do not disturb this default setting. SERIALNUMBER – If the SMI-S provider has been implemented as a proxy, then such a provider can be configured to manage multiple storage devices. This is why, you will have to explicitly specify which storage system you want the eG agent to monitor. Since each storage system is uniquely identified by a SERIALNUMBER, specify the same here. The serial number for an EMC CLARiiON device will be of the format, FCNMM094900059. NAMESPACE - Specify the namespace that uniquely identifies the profiles specific to the provider in use. For EMC CLARiiON, this parameter will be set to <i>root/emc</i> by default. 			
Outputs of the test	One set of results for each LUN on the storage system			
Measurements made by the	<table border="1"> <thead> <tr> <th>Measurement</th> <th>Measurement Unit</th> <th>Interpretation</th> </tr> </thead> </table>	Measurement	Measurement Unit	Interpretation
Measurement	Measurement Unit	Interpretation		

test	<p>Health state: Indicates how healthy this LUN currently is.</p>		<p>The values that this measure can report and their corresponding numeric values are discussed in the table below:</p> <table border="1" data-bbox="975 340 1372 853"> <thead> <tr> <th data-bbox="975 340 1122 418">Numeric Value</th><th data-bbox="1122 340 1372 418">Measure Value</th></tr> </thead> <tbody> <tr> <td data-bbox="975 418 1122 487">0</td><td data-bbox="1122 418 1372 487">OK</td></tr> <tr> <td data-bbox="975 487 1122 557">1</td><td data-bbox="1122 487 1372 557">Unknown</td></tr> <tr> <td data-bbox="975 557 1122 627">2</td><td data-bbox="1122 557 1372 627">Degraded/Warning</td></tr> <tr> <td data-bbox="975 627 1122 696">3</td><td data-bbox="1122 627 1372 696">Minor failure</td></tr> <tr> <td data-bbox="975 696 1122 766">4</td><td data-bbox="1122 696 1372 766">Major failure</td></tr> <tr> <td data-bbox="975 766 1122 836">5</td><td data-bbox="1122 766 1372 836">Critical failure</td></tr> <tr> <td data-bbox="975 836 1122 853">6</td><td data-bbox="1122 836 1372 853">Non-recoverable error</td></tr> </tbody> </table> <p> Note By default, this measure reports the Measure Values discussed above to indicate the state of a LUN. In the graph of this measure however, states are represented using the numeric equivalents only.</p>	Numeric Value	Measure Value	0	OK	1	Unknown	2	Degraded/Warning	3	Minor failure	4	Major failure	5	Critical failure	6	Non-recoverable error
Numeric Value	Measure Value																		
0	OK																		
1	Unknown																		
2	Degraded/Warning																		
3	Minor failure																		
4	Major failure																		
5	Critical failure																		
6	Non-recoverable error																		

	<p>Operational status: Indicates the current operational state of this LUN.</p>		<p>The values that this measure can report and their corresponding numeric values are discussed in the table below:</p> <table border="1"> <thead> <tr> <th>Numeric Value</th><th>Measure Value</th></tr> </thead> <tbody> <tr><td>0</td><td>OK</td></tr> <tr><td>1</td><td>In Service</td></tr> <tr><td>2</td><td>Power Mode</td></tr> <tr><td>3</td><td>Completed</td></tr> <tr><td>4</td><td>Starting</td></tr> <tr><td>5</td><td>Dormant</td></tr> <tr><td>6</td><td>Other</td></tr> <tr><td>7</td><td>Unknown</td></tr> <tr><td>8</td><td>Stopping</td></tr> <tr><td>9</td><td>Stressed</td></tr> <tr><td>10</td><td>Stopped</td></tr> <tr><td>11</td><td>Supporting Entity in Error</td></tr> <tr><td>12</td><td>Degraded or Predicted Failure</td></tr> <tr><td>13</td><td>Predictive Failure</td></tr> <tr><td>14</td><td>Lost Communication</td></tr> <tr><td>15</td><td>No Contact</td></tr> <tr><td>16</td><td>Aborted</td></tr> <tr><td>17</td><td>Error</td></tr> <tr><td>18</td><td>Non-Recoverable Error</td></tr> </tbody> </table>	Numeric Value	Measure Value	0	OK	1	In Service	2	Power Mode	3	Completed	4	Starting	5	Dormant	6	Other	7	Unknown	8	Stopping	9	Stressed	10	Stopped	11	Supporting Entity in Error	12	Degraded or Predicted Failure	13	Predictive Failure	14	Lost Communication	15	No Contact	16	Aborted	17	Error	18	Non-Recoverable Error
Numeric Value	Measure Value																																										
0	OK																																										
1	In Service																																										
2	Power Mode																																										
3	Completed																																										
4	Starting																																										
5	Dormant																																										
6	Other																																										
7	Unknown																																										
8	Stopping																																										
9	Stressed																																										
10	Stopped																																										
11	Supporting Entity in Error																																										
12	Degraded or Predicted Failure																																										
13	Predictive Failure																																										
14	Lost Communication																																										
15	No Contact																																										
16	Aborted																																										
17	Error																																										
18	Non-Recoverable Error																																										

			 Note	By default, this measure reports the Measure Values discussed above to indicate the operational state of a LUN. In the graph of this measure however, operational states are represented using the numeric equivalents only.
--	--	--	---	---

	<p>Detailed operational state:</p> <p>Describes the current operational state of this LUN.</p>		<p>This measure will be reported only if the API provides a detailed operational state.</p> <p>Typically, the detailed state will describe why the LUN is in a particular operational state. For instance, if the <i>Operational status</i> measure reports the value <i>Stopping</i> for a LUN, then this measure will explain why that LUN is being stopped.</p> <p>The values that this measure can report and their corresponding numeric values are discussed in the table below:</p> <table border="1" data-bbox="975 629 1372 1320"> <thead> <tr> <th data-bbox="975 629 1122 713">Numeric Value</th><th data-bbox="1122 629 1372 713">Measure Value</th></tr> </thead> <tbody> <tr> <td data-bbox="975 713 1122 783">0</td><td data-bbox="1122 713 1372 783">Online</td></tr> <tr> <td data-bbox="975 783 1122 853">1</td><td data-bbox="1122 783 1372 853">Success</td></tr> <tr> <td data-bbox="975 853 1122 922">2</td><td data-bbox="1122 853 1372 922">Power Saving Mode</td></tr> <tr> <td data-bbox="975 922 1122 971">3</td><td data-bbox="1122 922 1372 971">Write Protected</td></tr> <tr> <td data-bbox="975 971 1122 1041">4</td><td data-bbox="1122 971 1372 1041">Write Disabled</td></tr> <tr> <td data-bbox="975 1041 1122 1110">5</td><td data-bbox="1122 1041 1372 1110">Not Ready</td></tr> <tr> <td data-bbox="975 1110 1122 1180">6</td><td data-bbox="1122 1110 1372 1180">Removed</td></tr> <tr> <td data-bbox="975 1180 1122 1250">7</td><td data-bbox="1122 1180 1372 1250">Rebooting</td></tr> <tr> <td data-bbox="975 1250 1122 1320">8</td><td data-bbox="1122 1250 1372 1320">Offline</td></tr> <tr> <td data-bbox="975 1320 1122 1320">9</td><td data-bbox="1122 1320 1372 1320">Failure</td></tr> </tbody> </table> <p> By default, this measure reports the Measure Values discussed above to indicate the detailed operational state of a LUN. In the graph of this measure however, detailed operational states are represented using the numeric equivalents only.</p>	Numeric Value	Measure Value	0	Online	1	Success	2	Power Saving Mode	3	Write Protected	4	Write Disabled	5	Not Ready	6	Removed	7	Rebooting	8	Offline	9	Failure
Numeric Value	Measure Value																								
0	Online																								
1	Success																								
2	Power Saving Mode																								
3	Write Protected																								
4	Write Disabled																								
5	Not Ready																								
6	Removed																								
7	Rebooting																								
8	Offline																								
9	Failure																								
	<p>Data transmitted:</p> <p>Indicates the rate at which data was transmitted by this LUN.</p>	MB/Sec																							

	IOPS: Indicates the rate at which I/O operations were performed on this LUN.	IOPS	Compare the value of this measure across LUNs to know which LUN handled the maximum number of I/O requests and which handled the least. If the gap between the two is very high, then it indicates serious irregularities in load-balancing across LUNs. You may then want to take a look at the <i>Reads</i> and <i>Writes</i> measures to understand what to fine-tune – the load-balancing algorithm for read requests or that of the write requests.
	Reads: Indicates the rate at which read operations were performed on this LUN.	Reads/Sec	Compare the value of this measure across LUNs to know which LUN handled the maximum number of read requests and which handled the least.
	Writes: Indicates the rate at which write operations were performed on this LUN.	Writes/Sec	Compare the value of this measure across LUNs to know which LUN handled the maximum number of write requests and which handled the least.
	Data reads: Indicates the rate at which data is read from this LUN.	MB/Sec	Compare the value of these measures across LUNs to identify the slowest LUN in terms of servicing read and write requests (respectively).
	Data writes: Indicates the rate at which data is written to this LUN.	MB/Sec	
	LUN busy: Indicates the percentage of time this LUN was busy processing requests.	Percent	Compare the value of this measure across LUNs to know which LUN was the busiest and which LUN was not. If the gap between the two is very high, then it indicates serious irregularities in load-balancing across LUNs.
	Average read size: Indicates the amount of data read from this LUN per I/O operation	MB/Op	Compare the value of these measures across LUNs to identify the slowest LUN in terms of servicing read and write requests (respectively).
	Average write size: Indicates the amount of data written to this LUN per I/O operation.	MB/Op	

	Read hit: Indicates the percentage of read requests that were serviced by the cache of this LUN.	Percent	A high value is desired for this measure. A very low value is a cause for concern, as it indicates that cache usage is very poor; this in turn implies that direct LUN accesses, which are expensive operations, are high.
	Write hit: Indicates the percentage of write requests that were serviced by the cache of this LUN.	Percent	A high value is desired for this measure. A very low value is a cause for concern, as it indicates that cache usage is very poor; this in turn implies that direct LUN accesses, which are expensive operations, are high.
	Average response time: Indicates the time taken by this LUN to respond to I/O requests.	Microsecs	Ideally, this value should be low. If not, it implies that the LUN is slow.
	EMC queue length: Indicates the number of requests that are in queue for this LUN.	Number	A consistent increase in this value indicates a potential processing bottleneck with the LUN.
	EMC disk crossings: Indicates the number of times an I/O crossed a stripe boundary on a RAID 6, RAID 5, RAID 0, or RAID 1/O LUN.	Number	<p>A CLARiiON LUN appears to the host as an OS device. Typically, to use the disk device, it has to be formatted with disk partitions. Then OS file systems are created in one or some of the disk partitions formatted.</p> <p>Typically, from a striped LUN, OS disk formatting would create a partition, with a disk partition header. Then, an OS file system is created on that disk partition. As OS files are added to the the file system. the first file will have a piece sitting on the first stripe element of the LUN (for example, 64 KB). So, if we try to do an I/O of 64 KB on this OS file, part of the data will end up going to the first stripe element, which belongs to one physical drive, and the rest to the second drive that makes up the striped LUN. This type of drive crossing is called a stripe crossing. Striped crossing results in less efficient dispatches of I/O requests from the CLARion storage processors to the back-end disk drives, thereby reducing request service efficiency. This is why, ideally, the value of this measure should be very low.</p>
	Prefetched: Indicates the amount of data prefetched in the read cache of this LUN.	KB	Prefetching is read-ahead caching. It lets the SP anticipate the data an application will request so that it can read it from disk into its read cache before the data is needed.

	Prefetched not used: Indicates the amount of prefetched data in the read cache of this LUN that was not read during the last measurement period.	KB	If the value of this measure keeps growing for a LUN, you may want to fine-tune the pre-fetching to ensure that that LUN's read cache is not unnecessarily filled with data that is not usable. For instance, you may want to reduce the <i>Maximum Prefetch</i> value for a LUN, so that the storage system does not allow too many disk blocks to be prefetched for variable-length prefetching.
	EMC queue arrivals: Indicates the number of times a user request arrived while at least one other request was being processed.	Number	
	Utilization through SPA: Indicates the amount of data that was utilized in this LUN during storage processor A.	KB	Compare the value of this measure across LUNs to identify the top data consumers through SP A.
	Utilization through SPB: Indicates the amount of data that was utilized in this LUN during storage processor B.	KB	Compare the value of this measure across LUNs to identify the top data consumers through SP B.
	Response through SPA: Indicates the time taken by this LUN to respond to I/O requests through storage processor A.	Microsec	Compare the value of this measure across LUNs to identify the least responsive LUN through SP A.
	Response through SPB: Indicates the time taken by this LUN to respond to I/O requests through storage processor B.	Microsec	Compare the value of this measure across LUNs to identify the least responsive LUN through SP B.

1.7 The EMC Cache Layer

A storage-system cache has two parts: a **read cache** and a **write cache**. The read cache uses a read-ahead mechanism that lets the storage system prefetch data from the disk. Therefore the data will be ready in the cache when the application needs it. The write cache buffers and optimizes writes by absorbing peak loads, combining small writes, and eliminating rewrites.

Measure the extent and effectiveness of cache usage using the test mapped to this layer.



Figure 1.20: The EMS Cache Layer

1.7.1 Clarion Cache Test

This test monitors the current state, size, and usage of the read and write caches supported by the storage system.

Purpose	Monitors the current state, size, and usage of the read and write caches supported by the storage system
Target of the test	An EMC CLARiiON storage device
Agent deploying the test	A remote agent
Configurable parameters for the test	<ol style="list-style-type: none"> TESTPERIOD – How often should the test be executed HOST – The IP address of the storage device PORT - The port number at which the storage device listens. The default is NULL. CLARIION IP - By default, the host IP will be displayed here. If the eG agent has also been configured to use the SMI-S provider for metrics collection, then the IP address of host on which the SMI-S provider has been installed, will be displayed here by default. In this case, you should change the value of this parameter to reflect the IP address of the EMC CLARiiON storage device. However, if the eG agent uses only the NaviSphere CLI for monitoring, then the default settings can remain. NAVISECCLIPATH - The eG agent uses the command-line utility, NaviSecCli.exe, which is part of the NaviSphere Management Suite, to communicate with and monitor the storage device. To enable the eG agent to invoke the CLI, configure the full path to the CLI in the NAVISECCLIPATH text box. USER NAME and PASSWORD - Provide the credentials of a user who is authorized to access the storage device in the user name and password text boxes. CONFIRM PASSWORD - Confirm the password by retyping it here. TIMEOUT - Indicate the duration (in seconds) for which this test should wait for a response from the storage device. By default, this is set to 120 seconds. Note that the 'TIMEOUT' value should always be set between 3 and 600 seconds only.
Outputs of the test	One set of results for the storage system being monitored

Measurements made by the test	Measurement	Measurement Unit	Interpretation						
	Read hit ratio: Indicates the percentage of read requests to this LUN that were serviced by the cache	Percent	Ideally, the value of this measure should be high. A low value indicates that many read requests are serviced by direct disk accesses, which is a more expensive operation in terms of processing overheads.						
	Write hit ratio: Indicates the percentage of write requests to this LUN that were serviced by the cache.	Percent	Ideally, the value of this measure should be high. A low value indicates that many write requests are serviced by direct disk accesses, which is a more expensive operation in terms of processing overheads.						
	Dirty cache pages: Indicates the number of dirty cache pages.	Number							
	Cache pages owned: Indicates the number of cache pages owned.	Number							
	SPA read cache state: Indicates the current state of the read cache for Storage Processor (SP) A.		<p>If the read cache of the storage processor (SP) A is enabled, then this measure will report the value <i>Enabled</i>. If not, then, this measure will report the value <i>Disabled</i>.</p> <p>The numeric values that correspond to each of the states discussed above are available in the table below:</p> <table border="1" data-bbox="887 1296 1421 1453"> <thead> <tr> <th data-bbox="887 1296 1127 1347">Numeric Value</th><th data-bbox="1127 1296 1421 1347">State</th></tr> </thead> <tbody> <tr> <td data-bbox="887 1347 1127 1398">1</td><td data-bbox="1127 1347 1421 1398">Enabled</td></tr> <tr> <td data-bbox="887 1398 1127 1453">0</td><td data-bbox="1127 1398 1421 1453">Disabled</td></tr> </tbody> </table> <p>Note:</p> <p>By default, this measure reports the values <i>Disabled</i> or <i>Enabled</i> to indicate the status of the read cache. The graph of this measure however, represents the cache status using the numeric equivalents - 0 or 1.</p>	Numeric Value	State	1	Enabled	0	Disabled
Numeric Value	State								
1	Enabled								
0	Disabled								

	<p>SPA write cache state: Indicates the current state of the write cache for Storage Processor (SP) A.</p>		<p>If the write cache of the storage processor (SP) A is enabled, then this measure will report the value <i>Enabled</i>. If not, then, this measure will report the value <i>Disabled</i>.</p> <p>The numeric values that correspond to each of the states discussed above are available in the table below:</p> <table border="1"> <thead> <tr> <th>Numeric Value</th><th>State</th></tr> </thead> <tbody> <tr> <td>1</td><td>Enabled</td></tr> <tr> <td>0</td><td>Disabled</td></tr> </tbody> </table> <p>Note: By default, this measure reports the values <i>Disabled</i> or <i>Enabled</i> to indicate the status of the write cache. The graph of this measure however, represents the cache status using the numeric equivalents - <i>0</i> or <i>1</i>.</p>	Numeric Value	State	1	Enabled	0	Disabled
Numeric Value	State								
1	Enabled								
0	Disabled								
	<p>SPA cache pages: Indicates the total number of pages in the cache of Storage Processor A.</p>	Number	For best performance, each Storage Processor (SP) should have the maximum amount of its memory in cache and should use the default settings for the cache properties. Therefore, ideally the number of memory pages in the cache should be high.						
	<p>SPA read cache size: Indicates the current size of the read cache of Storage Processor A.</p>	MB	The read cache holds data that is expected to be accessed in the near future. If a request for data that is in the cache arrives, the request can be serviced from the cache faster than from the disks. Each request satisfied from cache eliminates the need for a disk access, reducing disk load. If the workload exhibits a "locality of reference" behavior, where a relatively small set of data is accessed frequently and repeatedly, the read cache can improve performance. In read-intensive environments, where more than 70 percent of all requests are reads, the read cache should be large enough to accommodate the dataset that is most frequently accessed. For sequential reads from a LUN, data that is expected to be accessed by subsequent read requests is read (prefetched) into the cache before being requested. Therefore, for optimal performance, the read cache should be large enough to accommodate prefetched data for sequential reads from each LUN.						

	SPA write cache size: Indicates the current size of the write cache of Storage Processor A.	MB	Write cache serves as a temporary buffer where data is stored temporarily before it is written to the disks. Cache writes are far faster than disk writes. Also, write-cached data is consolidated into larger I/Os when possible, and written to the disks more efficiently. (This reduces the expensive small writes in case of RAID 5 LUNs.) Also, in cases where data is modified frequently, the data is overwritten in the cache and written to the disks only once for several updates in the cache. This reduces disk load. Consequently, the write cache absorbs write data during heavy load periods and writes them to the disks, in an optimal fashion, during light load periods. However, if the amount of write data during an I/O burst exceeds the write cache size, the cache fills. Subsequent requests must wait for cached data to be flushed and for cache pages to become available for writing new data. It is hence imperative that you rightly size the write cache.
	SPA free memory size: Indicates the amount of physical memory of storage processor A that is currently unused.	MB	
	SPA system buffer: Indicates the size of the system buffer of storage processor A.	MB	
	SPA physical memory: Indicates the total physical memory of storage processor A.	MB	

	<p>SPB read cache state: Indicates the current state of the read cache of storage processor B.</p>		<p>If the read cache of the storage processor (SP) B is enabled, then this measure will report the value <i>Enabled</i>. If not, then, this measure will report the value <i>Disabled</i>.</p> <p>The numeric values that correspond to each of the states discussed above are available in the table below:</p> <table border="1" data-bbox="882 481 1421 629"> <thead> <tr> <th data-bbox="882 481 1144 523">Numeric Value</th><th data-bbox="1144 481 1421 523">State</th></tr> </thead> <tbody> <tr> <td data-bbox="882 523 1144 566">1</td><td data-bbox="1144 523 1421 566">Enabled</td></tr> <tr> <td data-bbox="882 566 1144 629">0</td><td data-bbox="1144 566 1421 629">Disabled</td></tr> </tbody> </table> <p>Note: By default, this measure reports the values <i>Disabled</i> or <i>Enabled</i> to indicate the status of the read cache. The graph of this measure however, represents the cache status using the numeric equivalents - <i>0</i> or <i>1</i>.</p>	Numeric Value	State	1	Enabled	0	Disabled
Numeric Value	State								
1	Enabled								
0	Disabled								
	<p>SPB write cache state: Indicates the current state of the write cache of storage processor B.</p>		<p>If the write cache of the storage processor (SP) B is enabled, then this measure will report the value <i>Enabled</i>. If not, then, this measure will report the value <i>Disabled</i>.</p> <p>The numeric values that correspond to each of the states discussed above are available in the table below:</p> <table border="1" data-bbox="882 1157 1421 1305"> <thead> <tr> <th data-bbox="882 1157 1144 1199">Numeric Value</th><th data-bbox="1144 1157 1421 1199">State</th></tr> </thead> <tbody> <tr> <td data-bbox="882 1199 1144 1241">1</td><td data-bbox="1144 1199 1421 1241">Enabled</td></tr> <tr> <td data-bbox="882 1241 1144 1305">0</td><td data-bbox="1144 1241 1421 1305">Disabled</td></tr> </tbody> </table> <p>Note: By default, this measure reports the values <i>Disabled</i> or <i>Enabled</i> to indicate the status of the write cache. The graph of this measure however, represents the cache status using the numeric equivalents - <i>0</i> or <i>1</i>.</p>	Numeric Value	State	1	Enabled	0	Disabled
Numeric Value	State								
1	Enabled								
0	Disabled								
	<p>SPB cache pages: Indicates the number of pages read cache of storage processor B.</p>	Number	<p>For best performance, each Storage Processor (SP) should have the maximum amount of its memory in cache and should use the default settings for the cache properties. Therefore, ideally the number of memory pages in the cache should be high.</p>						

	SPB read cache size: Indicates the current size of the read cache of Storage Processor B.	MB	The read cache holds data that is expected to be accessed in the near future. If a request for data that is in the cache arrives, the request can be serviced from the cache faster than from the disks. Each request satisfied from cache eliminates the need for a disk access, reducing disk load. If the workload exhibits a "locality of reference" behavior, where a relatively small set of data is accessed frequently and repeatedly, the read cache can improve performance. In read-intensive environments, where more than 70 percent of all requests are reads, the read cache should be large enough to accommodate the dataset that is most frequently accessed. For sequential reads from a LUN, data that is expected to be accessed by subsequent read requests is read (prefetched) into the cache before being requested. Therefore, for optimal performance, the read cache should be large enough to accommodate prefetched data for sequential reads from each LUN.
	SPB write cache size: Indicates the current size of the write cache of Storage Processor B.		Write cache serves as a temporary buffer where data is stored temporarily before it is written to the disks. Cache writes are far faster than disk writes. Also, write-cached data is consolidated into larger I/Os when possible, and written to the disks more efficiently. (This reduces the expensive small writes in case of RAID 5 LUNs.) Also, in cases where data is modified frequently, the data is overwritten in the cache and written to the disks only once for several updates in the cache. This reduces disk load. Consequently, the write cache absorbs write data during heavy load periods and writes them to the disks, in an optimal fashion, during light load periods. However, if the amount of write data during an I/O burst exceeds the write cache size, the cache fills. Subsequent requests must wait for cached data to be flushed and for cache pages to become available for writing new data. It is hence imperative that you rightly size the write cache.
	SPB free memory size: Indicates the amount of memory unused with storage processor B.	MB	

	SPB system buffer: Indicates the size of the system buffer of storage processor B.	MB							
	SPB physical memory: Indicates the total physical memory of storage processor B.	MB							
	SP read cache state: Indicates the state of the read cache of the storage processor.		<p>If the read cache of the storage processor (SP) is enabled, then this measure will report the value <i>Enabled</i>. If not, then, this measure will report the value <i>Disabled</i>.</p> <p>The numeric values that correspond to each of the states discussed above are available in the table below:</p> <table border="1"> <thead> <tr> <th>Numeric Value</th> <th>State</th> </tr> </thead> <tbody> <tr> <td>1</td> <td>Enabled</td> </tr> <tr> <td>0</td> <td>Disabled</td> </tr> </tbody> </table> <p>Note:</p> <p>By default, this measure reports the values <i>Disabled</i> or <i>Enabled</i> to indicate the status of the read cache. The graph of this measure however, represents the cache status using the numeric equivalents - <i>0</i> or <i>1</i>.</p>	Numeric Value	State	1	Enabled	0	Disabled
Numeric Value	State								
1	Enabled								
0	Disabled								
	SP write cache state: Indicates the current state of the write cache of the storage processor.		<p>If the write cache of the storage processor (SP) is enabled, then this measure will report the value <i>Enabled</i>. If not, then, this measure will report the value <i>Disabled</i>.</p> <p>The numeric values that correspond to each of the states discussed above are available in the table below:</p> <table border="1"> <thead> <tr> <th>Numeric Value</th> <th>State</th> </tr> </thead> <tbody> <tr> <td>1</td> <td>Enabled</td> </tr> <tr> <td>0</td> <td>Disabled</td> </tr> </tbody> </table> <p>Note:</p> <p>By default, this measure reports the values <i>Disabled</i> or <i>Enabled</i> to indicate the status of the write cache. The graph of this measure however, represents the cache status using the numeric equivalents - <i>0</i> or <i>1</i>.</p>	Numeric Value	State	1	Enabled	0	Disabled
Numeric Value	State								
1	Enabled								
0	Disabled								

	Cache page size: Indicates the number of pages currently in cache.	Number	To service I/O requests faster, to reduce disk overloads, and to eliminate disk abuse, the read/write caches should be sized with sufficient memory pages. Ideally, a cache page can be of size 2, 4, 8, or 16 KB. As a general guideline, EMC suggests 8 KB. The ideal cache page size depends on the operating system and application.						
	Write cache mirrored: Indicates the write cache mirrored status.		<p>Each storage processor (SP) has a write cache in its memory, which mirrors the write cache on the other SP. Because these caches mirror each other, they are always either enabled or disabled, and always the same size. On powerup, a storage system automatically enables the write cache on each SP if the write cache size is <i>non-zero</i>.</p> <p>Using this measure, you can determine whether the write cache of both SPs is currently enabled/disabled.</p> <p>If the write cache is disabled, then this measure will report the value <i>Enabled</i>. If not, the measure will report the value <i>Disabled</i>.</p> <p>The numeric values that correspond to each of the states discussed above are available in the table below:</p> <table border="1" data-bbox="889 1142 1421 1290"> <thead> <tr> <th>Numeric Value</th> <th>State</th> </tr> </thead> <tbody> <tr> <td>1</td> <td>Enabled</td> </tr> <tr> <td>0</td> <td>Disabled</td> </tr> </tbody> </table> <p>Note:</p> <p>By default, this measure reports the values <i>Disabled</i> or <i>Enabled</i> to indicate the status of the write cache. The graph of this measure however, represents the cache status using the numeric equivalents - <i>0</i> or <i>1</i>.</p>	Numeric Value	State	1	Enabled	0	Disabled
Numeric Value	State								
1	Enabled								
0	Disabled								

1.8 The EMC Storage Processor Layer

The tests mapped to this layer monitor the current state, I/O load, and overall health of each storage port and each storage processor on the EMC CLARiON device.



Figure 1.21: The tests mapped to the EMC Storage Processor layer

1.8.1 Clariion Storage Ports Test

This test reports the current status and overall health of each port on each storage processor supported by the storage system being monitored.

Purpose	Reports the current status and overall health of each port on each storage processor supported by the storage system being monitored
Target of the test	An EMC CLARiON storage device
Agent deploying the test	A remote agent

Configurable parameters for the test	<ol style="list-style-type: none"> 1. TESTPERIOD – How often should the test be executed 2. HOST – The IP address of the storage device 3. PORT - The port number at which the storage device listens. The default is NULL. 4. CLARIION IP - By default, the host IP will be displayed here. If the eG agent has also been configured to use the SMI-S provider for metrics collection, then the IP address of host on which the SMI-S provider has been installed, will be displayed here by default. In this case, you should change the value of this parameter to reflect the IP address of the EMC CLARIION storage device. However, if the eG agent uses only the NaviSphere CLI for monitoring, then the default settings can remain. 5. NAVISECCLIPATH - The eG agent uses the command-line utility, NaviSecCli.exe, which is part of the NaviSphere Management Suite, to communicate with and monitor the storage device. To enable the eG agent to invoke the CLI, configure the full path to the CLI in the NAVISECCLIPATH text box. 6. USER NAME and PASSWORD - Provide the credentials of a user who is authorized to access the storage device in the user name and password text boxes. 7. CONFIRM PASSWORD - Confirm the password by retyping it here. 8. IGNORE DISABLED SPOTS - By default, this flag is set to No, indicating that the test monitors all ports on all storage processors by default. Set this flag to Yes if you want the test to consider only the 'enabled' storage processor ports for monitoring. 9. EXCLUDE SPOTS - Provide a comma-separated list of <i>PortName PortID</i> pairs that you want to exclude from the monitoring scope of this test. For instance, your specification can be: <i>SPA 0,SPA 1,SPB 2</i>. By default, this is set to <i>none</i> indicating that no ports are excluded by default. 10. TIMEOUT - Indicate the duration (in seconds) for which this test should wait for a response from the storage device. By default, this is set to 120 seconds. Note that the 'TIMEOUT' value should always be set between 3 and 600 seconds only. 		
Outputs of the test	One set of results for each storage processor port on the storage system		
Measurements made by the	Measurement	Measurement Unit	Interpretation

test	<p>Link state: Indicates the link state of this storage processor port.</p>		<p>If the storage port is up and running, then this measure will report the value <i>Up</i>. If not, then, this measure will report the value <i>Down</i>.</p> <p>The numeric values that correspond to each of the states discussed above are available in the table below:</p> <table border="1" data-bbox="894 454 1421 593"> <thead> <tr> <th data-bbox="894 454 1122 487">Numeric Value</th><th data-bbox="1122 454 1421 487">State</th></tr> </thead> <tbody> <tr> <td data-bbox="1024 508 1051 536">1</td><td data-bbox="1274 508 1317 536">Up</td></tr> <tr> <td data-bbox="1024 557 1051 585">0</td><td data-bbox="1258 557 1323 585">Down</td></tr> </tbody> </table> <p>Note: By default, this measure reports the values <i>Up</i> or <i>Down</i> to indicate the status of a port. The graph of this measure however, represents the port status using the numeric equivalents - <i>0</i> or <i>1</i>.</p>	Numeric Value	State	1	Up	0	Down		
Numeric Value	State										
1	Up										
0	Down										
	<p>Port state: Indicates the current state of this port.</p>	Status	<p>The operational state of a port can be <i>Online</i>, <i>Offline</i> or <i>Not Applicable</i>.</p> <p>The numeric values that correspond to each of the states discussed above are available in the table below:</p> <table border="1" data-bbox="894 1036 1421 1227"> <thead> <tr> <th data-bbox="894 1036 1122 1070">Numeric Value</th><th data-bbox="1122 1036 1421 1070">State</th></tr> </thead> <tbody> <tr> <td data-bbox="1024 1091 1051 1119">1</td><td data-bbox="1274 1091 1323 1119">Online</td></tr> <tr> <td data-bbox="1024 1140 1051 1167">2</td><td data-bbox="1258 1140 1323 1167">Offline</td></tr> <tr> <td data-bbox="1024 1189 1051 1216">0</td><td data-bbox="1209 1189 1356 1216">Not Applicable</td></tr> </tbody> </table> <p>Note: By default, this measure reports the values <i>Up</i> or <i>Down</i> to indicate the status of a port. The graph of this measure however, represents the port status using the numeric equivalents - <i>0</i> or <i>1</i>.</p>	Numeric Value	State	1	Online	2	Offline	0	Not Applicable
Numeric Value	State										
1	Online										
2	Offline										
0	Not Applicable										

	<p>SFP state: Indicates the SFP state of this port.</p>	Number	<p>This measure can report any one of the following values:</p> <ul style="list-style-type: none"> • <i>Online</i> • <i>Faulted</i> • <i>Removed</i> <p>The numeric values that correspond to each of the states discussed above are available in the table below:</p> <table border="1"> <thead> <tr> <th>Numeric Value</th><th>State</th></tr> </thead> <tbody> <tr> <td>1</td><td>Online</td></tr> <tr> <td>2</td><td>Faulted</td></tr> <tr> <td>0</td><td>Removed</td></tr> </tbody> </table> <p>Note: By default, this measure reports the values <i>Up</i> or <i>Down</i> to indicate the status of a port. The graph of this measure however, represents the port status using the numeric equivalents - <i>0</i> or <i>1</i>.</p>	Numeric Value	State	1	Online	2	Faulted	0	Removed
Numeric Value	State										
1	Online										
2	Faulted										
0	Removed										
	<p>Reads: Indicates the number of reads per second made on this port.</p>	Number	Comparing the value of these measures across ports will clearly indicate which port is overloaded – it could also shed light on irregularities in load balancing across the ports.								
	<p>Writes: Indicates the number of writes per second made on this port.</p>	Number									
	<p>Data reads: Indicates the rate at which data is read through this port.</p>	Blocks/Sec									
	<p>Data writes: Indicates the rate at which data is written through this port.</p>	Blocks/Sec									

1.8.2 Clariion Storage Processors Test

The storage processor enables the administrator in serving the purpose of the following:

- Creating raid group

- Binding luns
- All CLI commands can be executed
- Read/write operations from external server to SAN

This test monitors the current state and I/O activity on each of the storage processors supported by the storage system.

Purpose	Reports the current status and overall health of each storage processor supported by the storage system being monitored		
Target of the test	An EMC CLARiiON storage device		
Agent deploying the test	A remote agent		
Configurable parameters for the test	<ol style="list-style-type: none"> 1. TESTPERIOD – How often should the test be executed 2. HOST – The IP address of the storage device 3. PORT - The port number at which the storage device listens. The default is NULL. 4. CLARIION IP - By default, the host IP will be displayed here. If the eG agent has also been configured to use the SMI-S provider for metrics collection, then the IP address of host on which the SMI-S provider has been installed, will be displayed here by default. In this case, you should change the value of this parameter to reflect the IP address of the EMC CLARiiON storage device. However, if the eG agent uses only the NaviSphere CLI for monitoring, then the default settings can remain. 5. NAVISECCLIPATH - The eG agent uses the command-line utility, NaviSecCli.exe, which is part of the NaviSphere Management Suite, to communicate with and monitor the storage device. To enable the eG agent to invoke the CLI, configure the full path to the CLI in the NAVISECCLIPATH text box. 6. USER NAME and PASSWORD - Provide the credentials of a user who is authorized to access the storage device in the user name and password text boxes. 7. CONFIRM PASSWORD - Confirm the password by retyping it here. 8. TIMEOUT - Indicate the duration (in seconds) for which this test should wait for a response from the storage device. By default, this is set to 120 seconds. Note that the 'TIMEOUT' value should always be set between 3 and 600 seconds only. 		
Outputs of the test	One set of results for each storage processor on the storage system		
Measurements made by the	Measurement	Measurement Unit	Interpretation

test	<p>Fault state: Indicates the current state of this storage processor.</p>		<p>If the storage processor is up and running, then the value of this measure will be <i>On</i>. If not, then this measure will report the value <i>Off</i>.</p> <p>The numeric values that correspond to the aforesaid states are as follows:</p> <table border="1" data-bbox="887 418 1421 566"> <thead> <tr> <th data-bbox="887 418 1144 460">Numeric Value</th><th data-bbox="1144 418 1421 460">State</th></tr> </thead> <tbody> <tr> <td data-bbox="887 460 1144 502">1</td><td data-bbox="1144 460 1421 502">On</td></tr> <tr> <td data-bbox="887 502 1144 566">0</td><td data-bbox="1144 502 1421 566">Off</td></tr> </tbody> </table> <p>Note: By default, this measure reports the values <i>On</i> or <i>Off</i> to indicate the status of a storage processor. The graph of this measure however, represents the processor status using the numeric equivalents - <i>0</i> or <i>1</i>.</p>	Numeric Value	State	1	On	0	Off
Numeric Value	State								
1	On								
0	Off								
	<p>Busy: Indicates percent utilization of the storage processor.</p>	Percent	<p>The numeric value that corresponds to individual states are listed below:</p> <ul style="list-style-type: none"> • 90%-Critical • 80%-Major • 60%-Minor 						
	<p>Idle: Indicates the percentage of time for which this storage processor was idle.</p>	Percent	<p>This value varies with respect to the value of the <i>Busy</i> measure.</p>						
	<p>Read requests: Indicates the rate of read requests to this storage processor.</p>	Req/Sec	<p>Comparing the value of these measures across storage processors will clearly indicate which processor is overloaded – it could also shed light on irregularities in load balancing across the processors.</p>						
	<p>Write requests: Indicates the rate of write requests to this storage processor.</p>	Req/Sec							
	<p>Total throughput: Indicates the sum of read and write request rates.</p>	I/O/Sec							

	Data writes: Indicates the rate at which data is written via this storage processor.	Blocks/Sec	
	Data reads: Indicates the rate at which data is read via this storage processor.	Blocks/Sec	

1.8.3 EMC RAID Arrays Test

This test monitors the current state, overall health, and the load-balancing capability of each storage array in the EMC CLARiiON storage system. With the help of this test, administrators can be proactively alerted to potential array failures / slowdowns / overload conditions. This way, irregularities in the distribution of I/O load across arrays comes to light, prompting administrators to fine-tune the load-balancing algorithm.

This test is disabled by default. To enable the test, first select the **Enable/Disable** option from the **Tests** menu of the **Agents** tile. Then, select *EMC Clarion SAN* as the **Component type**, pick this test from the **DISABLED TESTS** list, click the **<** button to enable it, and click the **Update** button.

Purpose	Monitors the current state, overall health, and the load-balancing capability of each storage array in the EMC CLARiiON storage system
Target of the test	An EMC CLARiiON storage device
Agent deploying the test	A remote agent

Configurable parameters for the test	<ol style="list-style-type: none"> 1. TEST PERIOD – How often should the test be executed 2. HOST – The IP address of the storage device 3. PORT - The port number at which the storage device listens. The default is NULL. 4. USER and PASSWORD – The SMI-S Provider is paired with the EMC CIM Object Manager Server to provide an SMI-compliant interface for CLARiiON arrays. Against the USER and PASSWORD parameters, specify the credentials of a user who has been assigned Monitor access to the EMC CIM Object Manager Server paired with EMC CLARiiON's SMI-S provider. 5. CONFIRM PASSWORD – Confirm the PASSWORD by retyping it here. 6. SSL – Set this flag to Yes, if the storage device being monitored is SSL-enabled. 7. ISEMBEDDED – By default, this flag is set to False for an EMC CLARiiON device. Do not disturb this default setting. 8. SERIALNUMBER – If the SMI-S provider has been implemented as a proxy, then such a provider can be configured to manage multiple storage devices. This is why, you will have to explicitly specify which storage system you want the eG agent to monitor. Since each storage system is uniquely identified by a SERIALNUMBER, specify the same here. The serial number for an EMC CLARiiON device will be of the format, FCNMM094900059. 9. NAMESPACE - Specify the namespace that uniquely identifies the profiles specific to the provider in use. For EMC CLARiiON, this parameter will be set to <i>root/emc</i> by default.
Outputs of the test	One set of results for each RAID array on the storage system

	<p>Operational status: Indicates the current operational state of this RAID array.</p>		<p>The values that this measure can report and their corresponding numeric values are discussed in the table below:</p> <table border="1"> <thead> <tr> <th>Numeric Value</th><th>Measure Value</th></tr> </thead> <tbody> <tr><td>0</td><td>OK</td></tr> <tr><td>1</td><td>In Service</td></tr> <tr><td>2</td><td>Power Mode</td></tr> <tr><td>3</td><td>Completed</td></tr> <tr><td>4</td><td>Starting</td></tr> <tr><td>5</td><td>Dormant</td></tr> <tr><td>6</td><td>Other</td></tr> <tr><td>7</td><td>Unknown</td></tr> <tr><td>8</td><td>Stopping</td></tr> <tr><td>9</td><td>Stressed</td></tr> <tr><td>10</td><td>Stopped</td></tr> <tr><td>11</td><td>Supporting Entity in Error</td></tr> <tr><td>12</td><td>Degraded or Predicted Failure</td></tr> <tr><td>13</td><td>Predictive Failure</td></tr> <tr><td>14</td><td>Lost Communication</td></tr> <tr><td>15</td><td>No Contact</td></tr> <tr><td>16</td><td>Aborted</td></tr> <tr><td>17</td><td>Error</td></tr> <tr><td>18</td><td>Non-Recoverable Error</td></tr> </tbody> </table>	Numeric Value	Measure Value	0	OK	1	In Service	2	Power Mode	3	Completed	4	Starting	5	Dormant	6	Other	7	Unknown	8	Stopping	9	Stressed	10	Stopped	11	Supporting Entity in Error	12	Degraded or Predicted Failure	13	Predictive Failure	14	Lost Communication	15	No Contact	16	Aborted	17	Error	18	Non-Recoverable Error
Numeric Value	Measure Value																																										
0	OK																																										
1	In Service																																										
2	Power Mode																																										
3	Completed																																										
4	Starting																																										
5	Dormant																																										
6	Other																																										
7	Unknown																																										
8	Stopping																																										
9	Stressed																																										
10	Stopped																																										
11	Supporting Entity in Error																																										
12	Degraded or Predicted Failure																																										
13	Predictive Failure																																										
14	Lost Communication																																										
15	No Contact																																										
16	Aborted																																										
17	Error																																										
18	Non-Recoverable Error																																										

			 Note	By default, this measure reports the Measure Values discussed above to indicate the operational state of a storage array. In the graph of this measure however, operational states are represented using the numeric equivalents only.
--	--	--	---	---

	<p>Detailed operational state:</p> <p>Describes the current operational state of this RAID array.</p>		<p>This measure will be reported only if the API provides a detailed operational state.</p> <p>Typically, the detailed state will describe why the storage array is in a particular operational state. For instance, if the <i>Operational status</i> measure reports the value <i>Stopping</i> for a storage array, then this measure will explain why that storage array is being stopped.</p> <p>The values that this measure can report and their corresponding numeric values are discussed in the table below:</p> <table border="1" data-bbox="975 629 1372 1320"> <thead> <tr> <th data-bbox="975 629 1122 713">Numeric Value</th><th data-bbox="1122 629 1372 713">Measure Value</th></tr> </thead> <tbody> <tr> <td data-bbox="975 713 1122 777">0</td><td data-bbox="1122 713 1372 777">Online</td></tr> <tr> <td data-bbox="975 777 1122 840">1</td><td data-bbox="1122 777 1372 840">Success</td></tr> <tr> <td data-bbox="975 840 1122 903">2</td><td data-bbox="1122 840 1372 903">Power Saving Mode</td></tr> <tr> <td data-bbox="975 903 1122 967">3</td><td data-bbox="1122 903 1372 967">Write Protected</td></tr> <tr> <td data-bbox="975 967 1122 1030">4</td><td data-bbox="1122 967 1372 1030">Write Disabled</td></tr> <tr> <td data-bbox="975 1030 1122 1094">5</td><td data-bbox="1122 1030 1372 1094">Not Ready</td></tr> <tr> <td data-bbox="975 1094 1122 1157">6</td><td data-bbox="1122 1094 1372 1157">Removed</td></tr> <tr> <td data-bbox="975 1157 1122 1220">7</td><td data-bbox="1122 1157 1372 1220">Rebooting</td></tr> <tr> <td data-bbox="975 1220 1122 1284">8</td><td data-bbox="1122 1220 1372 1284">Offline</td></tr> <tr> <td data-bbox="975 1284 1122 1320">9</td><td data-bbox="1122 1284 1372 1320">Failure</td></tr> </tbody> </table> <p> Note By default, this measure reports the Measure Values discussed above to indicate the detailed operational state of an array. In the graph of this measure however, detailed operational states are represented using the numeric equivalents only.</p>	Numeric Value	Measure Value	0	Online	1	Success	2	Power Saving Mode	3	Write Protected	4	Write Disabled	5	Not Ready	6	Removed	7	Rebooting	8	Offline	9	Failure
Numeric Value	Measure Value																								
0	Online																								
1	Success																								
2	Power Saving Mode																								
3	Write Protected																								
4	Write Disabled																								
5	Not Ready																								
6	Removed																								
7	Rebooting																								
8	Offline																								
9	Failure																								
	<p>Data transmitted:</p> <p>Indicates the rate at which data was transmitted by this RAID array.</p>	MB/Sec																							

	IOPS: Indicates the rate at which I/O operations were performed on this RAID array.	IOPS	Compare the value of this measure across storage arrays to know which storage array handled the maximum number of I/O requests and which handled the least. If the gap between the two is very high, then it indicates serious irregularities in load-balancing across storage arrays. You may then want to take a look at the <i>Reads</i> and <i>Writes</i> measures to understand what to fine-tune – the load-balancing algorithm for read requests or that of the write requests.
	Reads: Indicates the rate at which read operations were performed on this RAID array.	Reads/Sec	Compare the value of this measure across storage arrays to know which storage array handled the maximum number of read requests and which handled the least.
	Writes: Indicates the rate at which write operations were performed on this RAID array.	Writes/Sec	Compare the value of this measure across storage arrays to know which storage array handled the maximum number of write requests and which handled the least.
	Data reads: Indicates the rate at which data is read from this RAID array.	MB/Sec	Compare the value of these measures across storage arrays to identify the slowest storage array in terms of servicing read and write requests (respectively).
	Data written: Indicates the rate at which data is written to this RAID array.	MB/Sec	
	Average read size: Indicates the amount of data read from this RAID array per I/O operation	MB/Op	Compare the value of these measures across disks to identify the slowest disk in terms of servicing read and write requests (respectively).
	Average write size: Indicates the amount of data written to this RAID array per I/O operation.	MB/Op	
	Read hit: Indicates the percentage of read requests that were serviced by the cache of this RAID array.	Percent	A high value is desired for this measure. A very low value is a cause for concern, as it indicates that cache usage is very poor; this in turn implies that direct storage array accesses, which are expensive operations, are high.

	Write hit: Indicates the percentage of write requests that were serviced by the cache of this RAID array.	Percent	A high value is desired for this measure. A very low value is a cause for concern, as it indicates that cache usage is very poor; this in turn implies that direct storage array accesses, which are resource-intensive operations, are high.
	EFD data flushed SPA: Indicates the amount of data flushed to the EFDs from the write cache of this RAID array through storage processor A.	KB	One of the key features of EMC is the availability of Enterprise Flash Drives (EFDs). With this capability, EMC creates new ultra-performing "Tier 0" storage that removes the performance limitations of magnetic disk drives. EFDs increase performance of latency-sensitive applications, and are ideal for applications with high transaction rates and those requiring the fastest possible storage and retrieval.
	EFD data flushed SPB: Indicates the amount of data flushed to the EFDs from the write cache of this RAID array through storage processor B.	KB	<p>EMC CLARiiON storage arrays support both enabling and disabled read/write caches. The default recommendation is to turn off both read and write caches on all LUNs that reside on EFDs for the following reasons:</p> <ul style="list-style-type: none"> • EFDs are extremely fast, so when the read cache is enabled for the LUNs residing on them, the read cache lookup for each read is significantly higher as compared to FC drives, in an application profile that is not expected to get many read cache hits at any rate. So, it is faster to directly read from the EFDs. • If the storage array is being shared by several applications and is deployed with slower SATA drives, the write cache may be fully saturated, placing the EFDs in a force flush situation, which adds latency. In these situations, it is better to write the block directly to EFDs than to the write cache. <p>If the read and write caches are disabled, these measures will not report any values.</p>

	EFD dirty cache SPA: Indicates the percentage of pages in write cache that have received new data from hosts but have not yet been flushed to the EFD through storage processor A.	Percent	You should have a high percentage of dirty pages as it increases the chance of a read coming from cache or additional writes to the same block of data being absorbed by the cache. If an IO is served from cache the performance is better than if the data had to be retrieved from disk. That's why the default watermarks are usually around 60/80% or 70/90%. You don't want dirty pages to reach 100%, they should fluctuate between the high and low watermarks (which means the Cache is healthy). Periodic spikes or drops outside the watermarks are ok, but consistently hitting 100% indicates that the write cache is overstressed.
	EFD dirty cache SPB: Indicates the percentage of pages in write cache that have received new data from hosts but have not yet been flushed to the EFD through storage processor B.	Percent	

1.8.4 EMC RAID System Test

The storage processor enables the administrator in serving the purpose of the following:

- creating raid groups
- binding LUNs
- execute CLI commands
- perform read/write operations from external server to SAN

Excessive usage of or heavy I/O load on a single storage processor can cause a marked deterioration in the overall performance of the storage sub-system, as it is indicative of severe deficiencies in the load-balancing algorithm that drives the storage processors. Using the **EMC RAID System** test, administrators can easily monitor the current state, usage, and load on each of the storage processors on the storage system, quickly detect an overload condition, precisely point to the storage processor that is bearing its brunt, and promptly initiate measures to resolve the issue, so as to ensure the optimal performance of the storage system.

This test is disabled by default. To enable the test, first select the **Enable/Disable** option from the **Tests** menu of the **Agents** tile. Then, select *EMC Clariion SAN* as the **Component type**, pick this test from the **DISABLED TESTS** list, click the < button to enable it, and click the **Update** button.

Purpose	Using the RAID System test, administrators can easily monitor the current state, usage, and load on each of the storage processors on the storage system, quickly detect an overload condition, precisely point to the storage processor that is bearing its brunt, and promptly initiate measures to resolve the issue, so as to ensure the optimal performance of the storage system
Target of the test	An SMI-S compliant storage device
Agent deploying the	A remote agent

test			
Configurable parameters for the test	<ol style="list-style-type: none"> 1. TEST PERIOD – How often should the test be executed 2. HOST – The IP address of the storage device 3. PORT - The port number at which the storage device listens. The default is NULL. 4. USER and PASSWORD – The SMI-S Provider is paired with the EMC CIM Object Manager Server to provide an SMI-compliant interface for CLARiiON arrays. Against the USER and PASSWORD parameters, specify the credentials of a user who has been assigned Monitor access to the EMC CIM Object Manager Server paired with EMC CLARiiON's SMI-S provider. 5. CONFIRM PASSWORD – Confirm the PASSWORD by retyping it here. 6. SSL – Set this flag to Yes, if the storage device being monitored is SSL-enabled. 7. ISEMBEDDED – By default, this flag is set to False for an EMC CLARiiON device. Do not disturb this default setting. 8. SERIALNUMBER – If the SMI-S provider has been implemented as a proxy, then such a provider can be configured to manage multiple storage devices. This is why, you will have to explicitly specify which storage system you want the eG agent to monitor. Since each storage system is uniquely identified by a SERIALNUMBER, specify the same here. The serial number for an EMC CLARiiON device will be of the format, FCNMM094900059. 9. NAMESPACE - Specify the namespace that uniquely identifies the profiles specific to the provider in use. For EMC CLARiiON, this parameter will be set to <i>root/emc</i> by default. 		
Outputs of the test	One set of results for each storage processor on the storage system		
Measurements made by the test	Measurement	Measurement Unit	Interpretation

	<p>Operational status: Indicates the current operational state of this storage processor.</p>		<p>The values that this measure can report and their corresponding numeric values are discussed in the table below:</p> <table border="1"> <thead> <tr> <th>Numeric Value</th><th>Measure Value</th></tr> </thead> <tbody> <tr><td>0</td><td>OK</td></tr> <tr><td>1</td><td>In Service</td></tr> <tr><td>2</td><td>Power Mode</td></tr> <tr><td>3</td><td>Completed</td></tr> <tr><td>4</td><td>Starting</td></tr> <tr><td>5</td><td>Dormant</td></tr> <tr><td>6</td><td>Other</td></tr> <tr><td>7</td><td>Unknown</td></tr> <tr><td>8</td><td>Stopping</td></tr> <tr><td>9</td><td>Stressed</td></tr> <tr><td>10</td><td>Stopped</td></tr> <tr><td>11</td><td>Supporting Entity in Error</td></tr> <tr><td>12</td><td>Degraded or Predicted Failure</td></tr> <tr><td>13</td><td>Predictive Failure</td></tr> <tr><td>14</td><td>Lost Communication</td></tr> <tr><td>15</td><td>No Contact</td></tr> <tr><td>16</td><td>Aborted</td></tr> <tr><td>17</td><td>Error</td></tr> <tr><td>18</td><td>Non-Recoverable Error</td></tr> </tbody> </table>	Numeric Value	Measure Value	0	OK	1	In Service	2	Power Mode	3	Completed	4	Starting	5	Dormant	6	Other	7	Unknown	8	Stopping	9	Stressed	10	Stopped	11	Supporting Entity in Error	12	Degraded or Predicted Failure	13	Predictive Failure	14	Lost Communication	15	No Contact	16	Aborted	17	Error	18	Non-Recoverable Error
Numeric Value	Measure Value																																										
0	OK																																										
1	In Service																																										
2	Power Mode																																										
3	Completed																																										
4	Starting																																										
5	Dormant																																										
6	Other																																										
7	Unknown																																										
8	Stopping																																										
9	Stressed																																										
10	Stopped																																										
11	Supporting Entity in Error																																										
12	Degraded or Predicted Failure																																										
13	Predictive Failure																																										
14	Lost Communication																																										
15	No Contact																																										
16	Aborted																																										
17	Error																																										
18	Non-Recoverable Error																																										

			 Note	By default, this measure reports the Measure Values discussed above to indicate the operational state of a storage processor. In the graph of this measure however, operational states are represented using the numeric equivalents only.
--	--	--	---	---

	<p>Detailed operational status:</p> <p>Describes the current operational state of this storage processor.</p>	<p>This measure will be reported only if the API provides a detailed operational state.</p> <p>Typically, the detailed state will describe why the storage processor is in a particular operational state. For instance, if the <i>Operational status</i> measure reports the value <i>Stopping</i> for a storage processor, then this measure will explain why that storage processor is being stopped.</p> <p>The values that this measure can report and their corresponding numeric values are discussed in the table below:</p> <table border="1" data-bbox="975 656 1372 1353"> <thead> <tr> <th data-bbox="975 656 1122 741">Numeric Value</th><th data-bbox="1122 656 1372 741">Measure Value</th></tr> </thead> <tbody> <tr> <td data-bbox="975 741 1122 804">0</td><td data-bbox="1122 741 1372 804">Online</td></tr> <tr> <td data-bbox="975 804 1122 868">1</td><td data-bbox="1122 804 1372 868">Success</td></tr> <tr> <td data-bbox="975 868 1122 931">2</td><td data-bbox="1122 868 1372 931">Power Saving Mode</td></tr> <tr> <td data-bbox="975 931 1122 994">3</td><td data-bbox="1122 931 1372 994">Write Protected</td></tr> <tr> <td data-bbox="975 994 1122 1058">4</td><td data-bbox="1122 994 1372 1058">Write Disabled</td></tr> <tr> <td data-bbox="975 1058 1122 1121">5</td><td data-bbox="1122 1058 1372 1121">Not Ready</td></tr> <tr> <td data-bbox="975 1121 1122 1184">6</td><td data-bbox="1122 1121 1372 1184">Removed</td></tr> <tr> <td data-bbox="975 1184 1122 1248">7</td><td data-bbox="1122 1184 1372 1248">Rebooting</td></tr> <tr> <td data-bbox="975 1248 1122 1311">8</td><td data-bbox="1122 1248 1372 1311">Offline</td></tr> <tr> <td data-bbox="975 1311 1122 1353">9</td><td data-bbox="1122 1311 1372 1353">Failure</td></tr> </tbody> </table> <p> By default, this measure reports the Measure Values discussed above to indicate the detailed operational state of a storage processor. In the graph of this measure however, detailed operational states are represented using the numeric equivalents only.</p>	Numeric Value	Measure Value	0	Online	1	Success	2	Power Saving Mode	3	Write Protected	4	Write Disabled	5	Not Ready	6	Removed	7	Rebooting	8	Offline	9	Failure
Numeric Value	Measure Value																							
0	Online																							
1	Success																							
2	Power Saving Mode																							
3	Write Protected																							
4	Write Disabled																							
5	Not Ready																							
6	Removed																							
7	Rebooting																							
8	Offline																							
9	Failure																							

	Data transmitted: Indicates the rate at which data was transmitted by this storage processor.	MB/Sec	
	IOPS: Indicates the rate at which I/O operations were performed on this storage processor.	IOPS	<p>Compare the value of this measure across storage processors to know which storage processor handled the maximum number of I/O requests and which handled the least. If the gap between the two is very high, then it indicates serious irregularities in load-balancing across storage processors.</p> <p>You may then want to take a look at the <i>Reads</i> and <i>Writes</i> measures to understand what to fine-tune – the load-balancing algorithm for read requests or that of the write requests.</p>
	Reads: Indicates the rate at which read operations were performed on this storage processor.	Reads/Sec	Compare the value of this measure across storage processors to know which storage processor handled the maximum number of read requests and which handled the least.
	Writes: Indicates the rate at which write operations were performed on this storage processor.	Writes/Sec	Compare the value of this measure across storage processors to know which storage processor handled the maximum number of write requests and which handled the least.
	Data reads: Indicates the rate at which data is read from this storage processor.	MB/Sec	Compare the value of these measures across storage processors to identify the slowest storage processor in terms of servicing read and write requests (respectively).
	Data writes: Indicates the rate at which data is written to this storage processor.	MB/Sec	
	Average read size: Indicates the amount of data read from this storage processor per I/O operation	MB/Op	Compare the value of these measures across storage processors to identify the slowest storage processor in terms of servicing read and write requests (respectively).

	Average write size: Indicates the amount of data written to this storage processor per I/O operation.	MB/Op	
	Read hit: Indicates the percentage of read requests that were serviced by the cache of this storage processor.	Percent	A high value is desired for this measure. A very low value is a cause for concern, as it indicates that cache usage is very poor; this in turn implies that direct storage processor accesses, which are expensive operations, are high.
	Write hit: Indicates the percentage of write requests that were serviced by the cache of this storage processor.	Percent	A high value is desired for this measure. A very low value is a cause for concern, as it indicates that cache usage is very poor; this in turn implies that direct storage processor accesses, which are expensive operations, are high.
	High water flushes: Indicates the count of times data was flushed out of the write cache of this storage processor because a high watermark was violated.	Number	To regulate cache usage, watermark levels can be set using Navisphere Manager. Let's assume your Low Watermark (LWM) is set at 60% and your High Watermark (HWM) is at 80%. In this scenario, Clariion Algorithms will try to keep your cache levels between 60% and 80% since those are defined as the low and high watermarks. If for some reason the cache exceeds 80% occupancy (HWM), Forced Flushing kicks in disabling all the write cache in the Clariion.
	Idle water flushes: Indicates the count of times data was flushed out of the write cache of this storage processor via idle cache flushing.	Number	When a host is writing data to the connected Clariion Disk via cache on the Clariion, the Clariion takes that data, writes it to cache and acknowledges back to the host that the data has been written to disk. This data can actually be sitting in the cache or being written to the disk when this acknowledgement goes out. The process happens in 64 Kilobyte chunks when the data is being transferred to the disk from the cache. Due to large chunks of data coming in from the host, sometimes Idle Cache Flushing is not able to maintain the Low Watermark (LWM), in those cases Watermark Cache Flushing kicks in.

	Low water flushes: Indicates the count of times data was flushed out of the write cache of this storage processor because a low watermark was violated.	Number	Due to large chunks of data coming in from the host, sometimes Idle Cache Flushing is not able to maintain the Low Watermark (LWM), in those cases Watermark Cache Flushing kicks in.
	Write flushes: Indicates the number of requests to flush the write cache of this storage processor.	Number	
	Write cache flushed: Indicates the amount of data flushed out of the write cache of this storage processor.	KB	
	Queue arrivals: Indicates the number of times a user request arrived while at least one other request was being processed by this storage processor.	Number	
	Queue length: Indicates the count of queue length by arrivals for this storage processor.	Number	A consistent increase in the value of this measure could indicate a processing bottleneck.
	Dirty pages: Indicates the percentage of dirty pages currently in cache, that is, pages that have been modified in the SP's write cache, but that have not yet been written to disk.	Percent	A high percentage of dirty pages means the cache is handling many write requests.

1.9 EMC HBA Layer

A HBA, or Host Bus Adapter, is the interface card which connects a host to a SAN (Storage Area Network). It is an electronic circuit board and/or integrated circuit adapter that offers input/output (I/O) operations and physical connectivity among a server and a storage device.

Using the **Clariion HBA Ports** test attached to this layer, you can verify whether the HBA ports are connected to the fibre channel, and identify ports that are not trusted or defined.




Figure 1.22: The test mapped to the EMC HBAs layer

1.9.1 Clariion HBA Ports Test

Using this test, you can verify whether the HBA ports are currently connected to the fibre channel or not, and identify ports that are not trusted or defined.

Purpose	Verify whether the HBA ports are currently connected to the fibre channel or not, and identify ports that are not trusted or defined
Target of the test	An EMC CLARiON storage device
Agent deploying the test	A remote agent

Configurable parameters for the test	<ol style="list-style-type: none"> 1. TESTPERIOD – How often should the test be executed 2. HOST – The IP address of the storage device 3. PORT - The port number at which the storage device listens. The default is NULL. 4. CLARIION IP - By default, the host IP will be displayed here. If the eG agent has also been configured to use the SMI-S provider for metrics collection, then the IP address of host on which the SMI-S provider has been installed, will be displayed here by default. In this case, you should change the value of this parameter to reflect the IP address of the EMC CLARIION storage device. However, if the eG agent uses only the NaviSphere CLI for monitoring, then the default settings can remain. 5. NAVISECCLIPATH - The eG agent uses the command-line utility, NaviSecCli.exe, which is part of the NaviSphere Management Suite, to communicate with and monitor the storage device. To enable the eG agent to invoke the CLI, configure the full path to the CLI in the NAVISECCLIPATH text box. 6. USER NAME and PASSWORD - Provide the credentials of a user who is authorized to access the storage device in the user name and password text boxes. 7. CONFIRM PASSWORD - Confirm the password by retyping it here. 8. SHOW DEVICE NAME - This test reports measures for each HBA port on the storage system. By default, the test represents a HBA port as a unique combination of the <i>Server name</i> (i.e., the name of the server with which the HBA port is connecting), the <i>Storage Processor name</i>, and the <i>Storage Processor ID</i>. For instance, if the server named <i>n1pc20234</i> is connecting to the storage system via an HBA port using the storage processor, <i>SP A</i>, with ID <i>0</i>, then, by default, this HBA port will be represented as <i>n1pc20234 / SP A 0</i>, in the eG monitoring console. If you want to append the HBA device name also to this representation, then, set the show device name flag to Yes. By default, this flag is set to No. 9. DD FREQUENCY - - Refers to the frequency with which detailed diagnosis measures are to be generated for this test. The default is <i>1:1</i>. This indicates that, by default, detailed measures will be generated every time this test runs, and also every time the test detects a problem. You can modify this frequency, if you so desire. Also, if you intend to disable the detailed diagnosis capability for this test, you can do so by specifying <i>none</i> against dd frequency. 10. DETAILED DIAGNOSIS - To make diagnosis more efficient and accurate, the eG Enterprise suite embeds an optional detailed diagnostic capability. With this capability, the eG agents can be configured to run detailed, more elaborate tests as and when specific problems are detected. To enable the detailed diagnosis capability of this test for a particular server, choose the On option. To disable the capability, click on the Off option. The option to selectively enable/disable the detailed diagnosis capability will be available only if the following conditions are fulfilled: <ul style="list-style-type: none"> • The eG manager license should allow the detailed diagnosis capability • Both the normal and abnormal frequencies configured for the detailed diagnosis measures should not be 0. 11. TIMEOUT - Indicate the duration (in seconds) for which this test should wait for a response from the storage device. By default, this is set to 600 seconds. Note that the 'TIMEOUT' value should always be set between 3 and 600 seconds only.
--------------------------------------	--


Outputs of the test	One set of results for each HBA port on the storage device								
Measurements made by the test	Measurement	Measurement Unit	Interpretation						
	Logged in: Indicates whether this port is logged into the storage system or not.		<p>This measure reports the value <i>Yes</i> if the port is logged into the storage system, and <i>No</i> if it is not.</p> <p>The numeric values that correspond to each of the states discussed above are as follows:</p> <table border="1"> <thead> <tr> <th>Numeric Value</th><th>State</th></tr> </thead> <tbody> <tr> <td>0</td><td>No</td></tr> <tr> <td>1</td><td>Yes</td></tr> </tbody> </table> <p>Note:</p> <p>By default, this measure reports the States listed in the table above to indicate the logged in status of an HBA port. The graph of this measure however, represents logged in states using the numeric equivalents - <i>0 and 1</i>.</p> <p>You can use the detailed diagnosis of this measure to view additional details about the HBA.</p>	Numeric Value	State	0	No	1	Yes
Numeric Value	State								
0	No								
1	Yes								
	Trusted: Indicates whether/not the HBA port is trusted.		<p>This measure reports the value <i>Yes</i> if the port is trusted, and <i>No</i> if it is not.</p> <p>The numeric values that correspond to each of the states discussed above are as follows:</p> <table border="1"> <thead> <tr> <th>Numeric Value</th><th>State</th></tr> </thead> <tbody> <tr> <td>0</td><td>No</td></tr> <tr> <td>1</td><td>Yes</td></tr> </tbody> </table> <p>Note:</p> <p>By default, this measure reports the States listed in the table above to indicate the trust status of an HBA port. The graph of this measure however, represents trust states using the numeric equivalents - <i>0 and 1</i>.</p>	Numeric Value	State	0	No	1	Yes
Numeric Value	State								
0	No								
1	Yes								

	<p>Defined: Indicates whether / not the HBA port is defined.</p>	<p>This measure reports the value <i>Yes</i> if the port is defined, and <i>No</i> if it is not.</p> <p>The numeric values that correspond to each of the states discussed above are as follows:</p> <table border="1"> <thead> <tr> <th data-bbox="887 382 1144 424">Numeric Value</th><th data-bbox="1144 382 1421 424">State</th></tr> </thead> <tbody> <tr> <td data-bbox="887 424 1144 466">0</td><td data-bbox="1144 424 1421 466">No</td></tr> <tr> <td data-bbox="887 466 1144 530">1</td><td data-bbox="1144 466 1421 530">Yes</td></tr> </tbody> </table> <p>Note: By default, this measure reports the States listed in the table above to indicate the defined status of an HBA port. The graph of this measure however, represents defined states using the numeric equivalents - <i>0 and 1</i>.</p>	Numeric Value	State	0	No	1	Yes
Numeric Value	State							
0	No							
1	Yes							

The detailed diagnosis of the *Logged in* measure reveals additional details about an HBA, such as, the HBA UID, the IP address of the server with which it is communicating, the HBA Model, the HBA vendor, the HBA device driver name, the storage group name, and more.

HBA SP port details						
Time	HBA UID	Server IP Address	HBA Model Description	HBA Vendor Description	HBA Device Driver Name	StorageGroup Name
Mar 18, 2011 14:32:05	20:00:00:00:C9:95:5E:61:10:00:00:00:C9:95:5E:61	192.168.10.136	-	VMware ESXi 4.0.0	-	egvm109.mas.eginnovations.com

Figure 1.23: The detailed diagnosis of the Logged in measure



Conclusion

This document has clearly explained how eG Enterprise monitors the EMC CLARiiON device. We can thus conclude that eG Enterprise, with its ability to integrate remotely with the NaviSphere Manager, is the ideal solution for monitoring such SAN devices. For more information on eG Enterprise, please visit our web site at www.eginnovations.com or write to us at sales@eginnovations.com.